

**WISCONSIN**


**MODELS**

**S-10D • S-12D • S-14D**

---

**INSTRUCTION  
BOOK  
& PARTS LIST**

S - 10 D  
S - 12 D  
S - 14 D



 **WIS·CON  
TOTAL POWER CORP.**

---

# IMPORTANT

## READ THESE INSTRUCTIONS CAREFULLY

All points of operation and maintenance have been covered as carefully as possible but if further information is required, inquiries sent to the factory will receive prompt attention.

When writing the factory ALWAYS GIVE THE MODEL, SPECIFICATION AND SERIAL NUMBER of engine referred to.

## STARTING AND OPERATING OF NEW ENGINES

Careful breaking in of a new engine will greatly increase its life and result in trouble-free operation. A factory test is not sufficient to establish the polished bearing surfaces, which are so necessary to the proper performance and long life of an engine. Neither is there a quick way to force the establishment of good bearing surfaces. These can only be obtained by running a new engine carefully and under reduced speeds and loads for a short time, as follows:

First, be sure the engine is filled to the proper level with a good quality of engine oil, see "Grade of Oil" chart.

Before a new engine is put to its regular work, the engine should be operated at low idle speed (1000 to 1200 R.P.M.) for one half hour, without load. The R.P.M. should then be increased to engine operating speed, still without load, for an additional two hours.

If at all possible, operate the engine at light loads, for a period totaling about eight hours, before maximum load is applied. This will greatly increase engine life.

The various bearing surfaces in a new engine have not been glazed, as they will be with continued operation, and it is in this period of "running in," that special care must be exercised, otherwise the highly desired glaze will never be obtained. A new bearing surface that has once been damaged by carelessness will be ruined forever.

Our engine warranty is printed on the inside back cover of this manual. Read it carefully.

For Your Own Record

THIS MANUAL IS FOR MY WISCONSIN MODEL ..... ENGINE


SPEC. No. .... SERIAL No. ....

THE ABOVE INFORMATION, WHICH WILL BE FOUND ON THE INSTRUCTION PLATE ATTACHED TO THE AIR SHROUD OF THE ENGINE, SHOULD BE FILLED IN. YOUR PROMPT ATTENTION TO THIS MATTER WILL MAKE IT CONVENIENT FOR YOU IN THE FUTURE, AS THIS INFORMATION MUST BE GIVEN WHEN ORDERING ENGINE REPAIR PARTS.

# BOOK OF INSTRUCTIONS

# WISCONSIN *Air-Cooled*

## SINGLE CYLINDER ENGINES



READ THE *STARTING AND OPERATING INSTRUCTIONS* THOROUGHLY BEFORE STARTING A NEW ENGINE. BECOME ACQUAINTED WITH THE ENGINE COMPONENTS; THEIR LOCATION, MAINTENANCE AND ADJUSTMENT REQUIREMENTS.

LOCATED IN REAR SECTION OF MANUAL

*SOLID STATE – BREAKERLESS IGNITION SYSTEM*, Forms MY-115 and MY-101-4  
*FLYWHEEL ALTERNATOR, INSTRUCTIONS AND PARTS LIST*, Form MY-110-2

## Models

**S-10D**

3-1/4" Bore – 3" Stroke  
24.89 cu. in. Displacement

**S-12D**

3-1/2" Bore – 3" Stroke  
28.86 cu. in. Displacement

**S-14D**

3-3/4" Bore – 3" Stroke  
33.1 cu. in. Displacement

ISSUE MM-304  
JAN. 85

# INTRODUCTION

This manual has been compiled to suit the service requirements of the basic engine and accessories most commonly supplied with the engine.

Wis-Con Total Power adapts its engines to suit individual customer requirements when ever practical. However, it would become too involved to include all variations in one manual; therefore, should any problems arise concerning engine servicing, we advise that a Wis-Con Total Power Distributor or authorized Service Center be contacted, as they are capable of identifying all parts by the specification number stamped on the name plate of engine.

Wisconsin heavy duty air cooled engines are of the most advanced design and are built in a modern factory, equipped with the latest machinery available.

Only the best materials, most suitable for the particular part, are used. During production, every part is subjected to the most rigid inspection, as are also the completely assembled engines. After assembly, every engine is operated on its own power for several hours. All adjustments are carefully made so that each engine will be in perfect operating condition when it leaves the factory.

Wis-Con Total Power is backed by over seventy years of engineering experience in the design of internal-combustion engines for every conceivable type of service. The performance of the engines is proof of the long satisfactory service you too can expect from your engine.

Like all fine machinery, the engine must be given regular care and be operated in accordance with the instructions.

## Safety Precautions


- Never fill fuel tank while engine is running or hot; avoid the possibility of spilled fuel causing a fire.
- Always refuel slowly to avoid spillage.
- When starting engine, maintain a safe distance from moving parts of equipment.
- Do not start engine with clutch engaged.
- Do not operate engine in a closed building unless the exhaust is piped outside. This exhaust contains carbon monoxide, a poisonous, odorless and invisible gas, which if breathed causes serious illness and possible death.
- Never run engine with governor disconnected, or operate at speeds in excess of 3600 R.P.M. load.
- Never make adjustments on machinery while it is connected to the engine, without first removing the ignition cable from the spark plug. Turning the machinery over by hand during adjusting or cleaning might start the engine and machinery with it, causing serious injury to the operator.
- Precaution is the best insurance against accidents.

*Keep this book handy at all times, familiarize yourself with the operating instructions.*



## INDEX


	PAGE		PAGE
Air Cleaner .....	10	Governor – Description .....	7
Battery Ignition .....	11	Governor Operation .....	25
Bore and Stroke .....	1	Horsepower .....	7
Breaker Points .....	11	Ignition – Description .....	7
Breather – Crankcase .....	10	Ignition Spark .....	11
Carburetor Adjustment .....	9	Lubrication .....	7
Carburetor Repair – See Manufacturer's Bulletin in Back of Manual.		Lubrication System .....	7
Clutch Take-Off .....	15	Magneto Ignition .....	11
Clutch Adjustment .....	15	Magneto Service Instructions .....	12
Compression .....	17	Oil – Grade of and Classification .....	8
Compression Release .....	7-24	Parts List Section .....	27
Compression – Restoring .....	16	Reduction Gears .....	15
Cooling .....	7	Rotation .....	7
Cross Section of Engine .....	6	Safety Precautions .....	2
Disassembly and Reassembly .....	18	Service Station Directory – See Back of Manual.	
Breaker Push Pin and Bushing .....	24	Spark Plug .....	14
Camshaft and Valve Tappets .....	23	Starting and Operating Instructions .....	7
Carburetor and Air Cleaner .....	18	Starting – Procedure .....	8
Connecting Rod and Piston .....	22	Starting and Operation of New Engine (See Inside of Front Cover).	
Crankshaft .....	25	Stopping Engine .....	9
Cylinder Block .....	23	Storage of Engine for Winter .....	16
Cylinder Head and Spark Plug .....	19	Temperature Safety Switch .....	14
Flywheel .....	20	Testing Rebuilt Engine .....	18
Flywheel Shroud .....	19	Timing .....	12
Fuel Tank .....	18	Timing Marks .....	23
Gear Cover .....	21	Troubles – Causes and Remedies .....	16
Governor Flyweight Assembly .....	21	Backfires Through Carburetor .....	18
Piston, Ring and Rod Clearance Chart .....	23	Ignition .....	17
Piston Rings .....	23	Knocks .....	18
Starter Sheave .....	19	Misses .....	17
Stator Plate .....	25	Overheats .....	17
Valves and Seat Inserts .....	19	Starting Difficulties .....	16
Valve Guides .....	20	Stops .....	17
End Play .....	25	Surges or Gallops .....	17
Engine Illustration .....	4-5	Valves – Grinding and Tolerance Chart .....	19-20
Electrical Equipment (Motor-Generator) and Wiring Circuits .....	13-14	Tappet Adjustment .....	24
Fuel .....	8	Warm-Up Period – Overspeeding .....	9
Fuel Pump .....	8		
General Design .....	7		
Governor Adjustment – Engine Speed .....	25		



With 'ZENITH' Carburetor - See page 32A for engine with WALBRO carburetor

Fig. 1  
**TAKE-OFF (rear) and RIGHT HAND SIDE VIEW of ENGINE**

293058C-2



VENT HOLE IN CAP  
Keep clean.

FUEL TANK

AIR CLEANER  
Clean  
per instructions on decal.

FUEL SHUT-OFF VALVE  
AND STRAINER  
Remove and clean  
periodically.

Keep screen free  
from dirt and chaff.

ROPE STARTER or  
MOTOR-GENERATOR  
SHEAVE

FLYWHEEL SHROUD  
Do not operate engine without  
air shrouding or with badly  
dented shroud.

MAGNETO GROUND SWITCH  
Depress and hold  
until engine stops.

Fig. 2

FAN END (front) and RIGHT HAND SIDE VIEW of ENGINE

293051C-2




Fig. 3  
SECTIONAL VIEWS OF ENGINE

## GENERAL DESIGN

Wisconsin engines are of the *four cycle type*, in which each of the four operations of *suction, compression, expansion and exhaust* constitutes a complete stroke. This gives one power stroke for each two revolutions of the crankshaft.

### COMPRESSION RELEASE

A component part of the camshaft that operates automatically and trouble free. Permits fast and effortless starting with no dangerous "kick-back". Incorporated in these models of engines beginning with Serial No. 4225490.

### COOLING

Cooling is accomplished by a flow of air, circulated over the cylinder and head of the engine, by a combination fan-flywheel encased in a sheet metal shroud. The air is divided and directed by ducts and baffle plates to insure uniform cooling of all parts.

*Never operate an engine with any part of the shrouding removed, because this will retard the air cooling.*

*Keep the cylinder and head fins free from dirt and chaff. Improper circulation of cooling air will cause engine to overheat.*

### CARBURETOR

The proper combustible mixture of gasoline and air is furnished by a balanced carburetor, giving correct fuel to air ratios for all speeds and loads.

### IGNITION

The spark for ignition of the fuel mixture is furnished by a high tension *flywheel magneto*. A stator plate functions as an engine bearing plate as well as a support for the coil and core. The permanent magnet is mounted to the flywheel, and a breaker box on the side of the crankcase contains the points, condenser and stop switch. A push pin, actuated by the engine camshaft, operates the breaker arm at *half engine speed*.

*Battery ignition* (12 volt) can be furnished in place of magneto, when specified. An ignition coil and breaker assembly are the means of inducing high voltage to the spark plug. *Battery is not* furnished by Wisconsin Motor Corporation.

### LUBRICATION SYSTEM

An oil dipper attached to the connecting rod provides for a splash type lubrication system. The action of the dipper striking the oil in the crankcase provides ample lubrication for all internal parts of the engine.

### GOVERNOR

A governor of the centrifugal flyball type maintains the engine speed by varying the throttle opening to suit the load imposed upon the engine. These engines are equipped with either a *fixed speed* or *variable speed control*, to regulate the governed speed of the engine.

## ROTATION

The rotation of the crankshaft is *clockwise* when viewing from the flywheel or starting end of the engine. This gives *counter-clockwise* rotation at the power take-off end of the crankshaft.

*Horsepower* specified in the accompanying chart is for an atmospheric temperature of 60° Fahrenheit at sea level and at a Barometric pressure of 29.92 inches of mercury.

## HORSEPOWER

R.P.M.	MODELS		
	S-10D	S-12D	S-14D
1600	5.3	6.3	6.4
1800	5.9	7.2	7.3
2000	6.6	8.1	8.2
2200	7.3	9.0	9.1
2400	8.2	9.8	10.0
2600	8.7	10.5	10.8
2800	9.4	10.9	11.6
3000	9.7	11.6	12.4
3200	10.2	11.9	13.1
3400	10.4	12.2	13.7
3600	10.5	12.5	14.1

For each inch lower the Barometric pressure drops, there will be a loss in horsepower of 3½%.

For each 10° temperature rise there will be a reduction in horsepower of 1%.

For each 1000 ft. altitude above sea level there will be a reduction in horsepower of 3½%.

The friction in new engines cannot be reduced to the ultimate minimum during the regular block test, but engines are guaranteed to develop at least 85 per cent of maximum power when shipped from the factory. The power will increase as friction is reduced during the first few days of operation. The engine will develop at least 95% of maximum horsepower when friction is reduced to a minimum.

For continuous operation, allow 20% of horsepower shown as a safety factor.

## INSTRUCTIONS FOR STARTING AND OPERATING

### LUBRICATION

Before starting a new engine, fill crankcase base with the correct grade of engine oil, as specified in "*grade of oil chart*". Fill thru the filler plug opening, illustrated in *Fig. 4*, with 2 quarts of oil.

For *run-in* of new engines, use same oil as recommended in *Grade of Oil Chart*.

The *oil level* is indicated by a groove on the dip stick, as shown in *Fig. 4*. Check oil level by resting bottom of plug at the top of oil filler opening on gear cover. (Do not thread in place to check oil).

Too much emphasis cannot be given to the matter of oil selection. High grade oil of the body suited to the requirements of your engine is the most important single item in the economical operation of the unit, yet it is the cheapest item of operating cost. Select your oil solely on equality and suitability — never on price.

High-grade highly refined oils, corresponding in body to the S. A. E. (Society of Automotive Engineers) Viscosity Numbers listed in *Grade of Oil Chart*, will prove economical and assure long engine life.

### SERVICE CLASSIFICATION OF OIL

In addition to the S.A.E. Viscosity grades, oils are also classified according to severity of engine service. Use oils classified by the American Petroleum Institute as *Service MS, SD or SE*. This type of oil is for engines performing under unfavorable or severe operating conditions such as: high speeds, constant starting and stopping, operating in extreme high or low temperatures and excessive idling.

### GRADE OF OIL

SEASON OR TEMPERATURE	GRADE OF OIL
Spring, Summer or Fall + 120°F to + 40°F	SAE 30
Winter + 40°F to + 15°F + 15°F to 0°F Below Zero	SAE 20-20W SAE 10W SAE 5W-20
Use oils classified as Service MS, SD or SE	
Crankcase Capacity	2 Quarts

Follow summer recommendations in winter if engine is housed in warm building.

*Check oil level every 8 hours of operation.*

*The old oil should be drained and fresh oil added after every 50 hours of operation.*

*To drain oil;* remove drain plug at either side of crankcase base. Oil should be drained while engine is hot, as it will then flow more freely.

### FUEL

The fuel tank should be filled with a *good quality* gasoline free from dirt and water. The capacity of the standard tank is  $1\frac{1}{2}$  gallons. A larger,  $2\frac{1}{4}$  gallon tank, can be furnished upon request. Some of the poorer grades of gasoline contain gum which will deposit on valve stems, piston rings, and in the various small passages in the carburetor, causing serious trouble in operating, and in fact might prevent the engine from operating at all.

*Use only reputable, well known brands of gasoline of the REGULAR GRADE.*




Fig. 4

293053C

The gasoline should have an octane rating of at least 90. Fuel with a low octane rating will cause detonation, and if operation is continued under this condition, severe damage will result to the engine. The cylinder and piston will be scored, head gasket blown out, bearings will be damaged, etc.

Be sure that air vent in fuel tank cap is not plugged with dirt, as this would prevent fuel from flowing to the carburetor.

### FUEL PUMP

An engine equipped with fuel pump; when starting for the first time, or when engine has been out of operation for a while, should be primed to prevent hard starting. Disconnect ignition wire at the spark plug, then turn the engine over about 6 or 7 times by means of the rope starter sheave to actuate the fuel pump and thus fill the carburetor bowl with gasoline. Be sure and connect ignition wire after priming has been accomplished.

Fuel pump is an optional accessory and is usually furnished only upon request when engine is ordered. But, beginning with Serial No. 4080373, all crankcases for these models of engines are machined to accommodate field installation of a fuel pump. Instructions for fuel pump maintenance and repair are located in the back of this manual.

### STARTING

#### STARTING PROCEDURE (Fig. 5 and Fig. 6)

1. Check crankcase oil level and gasoline supply. Open fuel shut-off valve.
2. Disengage clutch, if furnished.
3. Set throttle about  $1/2$  open, if variable speed governor control is furnished. With a fixed speed governor, spring will hold throttle open for starting.






Fig. 5

293054C




Fig. 6

293055C

4. Close choke on carburetor by pushing choke lever down (lever in horizontal position). Wind rope fully on sheave and pull briskly to turn crankshaft over.

Above 30°F; open choke halfway if engine does not start after two or three pulls.

With starting motor; pull out ignition switch ("To Stop Push In"), and depress starter button.

5. After engine starts open choke fully (push lever up). Less choking is required in warmer weather or when the engine is warm, than when it is cold. Should flooding occur, open choke fully and continue cranking.

If all conditions are right, engine will start promptly after one or two attempts. Allow engine to warm up a few minutes before applying load, as prescribed in "Warm-Up Period" paragraphs.

New engines should be "run-in" gradually to insure trouble-free service. Refer to "Starting and Operation

of New Engine", on the inside front cover of this manual, for correct "running-in" procedure, with the exception that the initial break-in speed for the first half hour should be 1600 to 1800 R.P.M.

### WARM-UP PERIOD

The engine should be allowed to warm up to operating temperature before load is applied. This requires only a few minutes of running at moderate speed. *Racing an engine or gunning it*, to hurry the warm-up period, is very destructive to the polished wearing surfaces of piston rings, cylinder, bearings, etc., as the proper oil film on these various surfaces cannot be established until the oil has warmed up and become sufficiently fluid. This is especially important on new engines and in cool weather.

*Racing an engine by disconnecting the governor*, or by doing anything to interfere with the governed control engine speed, is extremely dangerous. The governor is provided as a means for controlling the engine speed to suit the load applied, and also as a safety measure to guard against excessive speeds, which not only overstrain all working parts, but which might wreck the engine and possibly injure bystanders.

All parts of the engine are designed to safely withstand any speeds which might normally be required, but it must be remembered that the stresses set up in rotating parts increase with the square of the speed. That means that if the speed is doubled, the stresses will be quadrupled, and if the speeds are trebled, the stresses will be nine times as great.

*Strict adherence to the above instructions cannot be too strongly urged, and greatly increased engine life will result as a reward for these easily applied recommendations.*

### STOPPING ENGINE

The breaker box on the side of the crankcase has a *magneto ground switch* for stopping the engine. *Depress and hold down until engine stops.* Engines with *motor-generator* or *battery ignition* have an ignition switch on control panel, "To Stop Push In".

If the engine has been running hard and is hot, do not stop it abruptly from full load, but remove the load and allow engine to run idle at 1000 to 1200 R.P.M. for three to five minutes. This will reduce the internal temperature of the engine much faster, minimize valve warping, and of course the external temperature, including the manifold and carburetor will also reduce faster, due to air circulation from the flywheel.

### CARBURETOR ADJUSTMENT (Fig. 6)

The *main metering jet* in the *standard engine* carburetor is of the *fixed type* and therefore no adjustment can be made.

On engines furnished with an *adjustable jet* carburetor, turn *main jet adjustment in* (clockwise), until it seats, then turn *out* (counter-clockwise)  $2\frac{1}{4}$  turns. After the engine is started, warmed up for several minutes and

running at normal operating speed, the needle valve should be readjusted for smooth operation. This adjustment need only be made the first time engine is started. In cold weather, starting may be facilitated by opening needle valve slightly more, then readjusted to normal running position after engine is started.

The correct amount of throttle plate opening for the proper low idle speed is obtained by means of the *throttle stop screw*. However, this is set at the factory so that no immediate adjustment is necessary. The *idle adjustment* is for smooth low speed operation and this adjustment, if necessary, must be made with the carburetor throttle lever closed. Normal idle setting is approximately 1½ turns off seat.

For further information, refer to Zenith operating and service instructions in the rear of this manual.

## MAINTENANCE

### AIR CLEANERS

These engines are provided with a *dry element* type air cleaner, as illustrated in *Fig. 7A*, with the previously standard *oil bath* air cleaner, *Fig. 7*, now furnished as optional equipment.

The air cleaner must be serviced frequently, depending on the dust conditions where engine is operated. Daily attention to the air cleaner is one of the most important considerations in prolonging engine life.

#### OIL BATH AIR CLEANER, (Fig. 7)

*Once each week*; the filtering element should be thoroughly washed in a solvent. Remove oil and clean out air cleaner bowl. Add fresh oil to the *level line* indicated on bowl, using the same grade oil as is used in the crankcase.

*Service daily*, if engine is operating in very dusty conditions. Detailed instructions are printed on the air cleaner.

*Operating the engine under dusty conditions without oil in the air cleaner or with dirty oil, may wear out cylinder, piston, rings and bearings in a few days time, and result in costly repairs.*

#### DRY ELEMENT AIR CLEANER, (Fig. 7A)

*Service daily*, if engine is operating in very dusty conditions. Remove cartridge and shake out the accumulated dirt (do not tap or strike element – it may become damaged). Wipe out dirt from inside cover.

*Once each week*; the filtering cartridge should be taken out and rinsed under a faucet with cold water, then wash by repeated dipping for several minutes in a solution of lukewarm water and a mild, *non-sudsing* detergent. Rinse in cold water from the inside out, and allow to dry overnight before installing. In cold weather, protect element from freezing until dry. *Excessive smoke or loss of power are good indications that the element requires cleaning.*

*Do not use gasoline, kerosene or solvent for cleaning – Do not oil element.*




Fig. 7

293057C




Fig. 7A

311747C

After five washings or one year of service, replace cartridge. New cartridges are available at your *Wisconsin Engine dealer*. Refer to parts list section for replacement part number.

### CRANKCASE BREATHER

A *reed type breather valve* is an integral part of the valve tappet inspection cover, as illustrated in *Fig. 8*. The valve maintains a partial vacuum in the crankcase, and thus eliminates internal crankcase pressure that would cause oil leaks at the seals, gaskets and breaker box. Keep complete breather system free from dirt. Clean breather valve by washing in solvent, and in reassembly mount with drain hole facing down.

*Oil in breaker box* may be the result of faulty breather action caused by dirt stuck between reed and seat. This condition can be remedied in the following manner:

1. With engine running at operating speed, pinch neoprene breather line so that it is completely shut off.






Fig. 8

293068C

2. Hold tubing closed, for a period of not more than 20 seconds, and then release.
3. If oil leak continues, repeat procedure after a 5 minute interval. If this does not remedy the condition; stop engine, take off inspection cover-breather assembly and wash in solvent.

### IGNITION SPARK

If difficulty is experienced in starting the engine or if engine misses firing, the strength of the ignition spark should be checked. Remove spark plug from cylinder head and connect ignition wire to it. Turn engine over several times by means of the rope starter sheave, as illustrated in Fig. 9, and observe the spark at the plug gap. If a good strong spark occurs, the ignition system can be eliminated as the source of trouble. If there is a weak spark or no spark at all, follow instructions in "Breaker Point Adjustment" par-




Fig. 9

293056C

agraphs. Also check ignition wires, spark plug, condenser and coil.

## MAGNETO IGNITION

### MAGNETO

The flywheel magneto used on this model of engine is made up of three component parts; *flywheel*, *stator plate* with coil, and *breaker assembly*. The *breaker box* mounted on the right hand side of the crankcase contains the *points*, *condenser* and *ground switch*.

## BATTERY IGNITION

### IGNITION COIL - 12 Volt

Engines furnished with battery ignition, instead of the standard magneto ignition system, use a conventional 12 volt ignition coil. The same *breaker point assembly* is used for both types of ignition, but the *flywheel* and fan end *bearing plate* differ.

The following "Breaker Point Adjustment" and "Timing" procedures apply for both *magneto* and *battery ignition* systems.

## BREAKER POINTS

### REPLACEMENT and ADJUSTMENT

The magneto *breaker points*, Fig. 10, are contained in The *breaker box* on the right hand side of the engine. A *push pin*, actuated by a *striker plate* mounted to the camshaft, operates the breaker points at *half engine speed*. When ever points are replaced, inspect push pin for possible wear and replace if necessary.

If *oil leaks* from breaker box, refer to "Crankcase Breather" for cleaning of breather valve seat.

At least twice each season or when ignition spark becomes weak, remove breaker box cover, inspect the points and check the gap opening. If there is evidence of pitting or pyramiding and it becomes necessary to resurface or replace points, it will also be necessary to readjust the gap and retune the engine.




Fig. 10




Fig. 11

293069C

**Replacement of points:** Turn crankshaft over so that breaker push pin is at its inner most position (low point of camshaft striker plate). Mount breaker assembly to crankcase by means of brass fulcrum pin, and tighten pin to 22 inch pounds torque (do not over-tighten). Be sure breaker arm spring is squarely mounted (if spring is cocked, points will be out of line). Mount lockscrew with washer and proceed with point adjustment and timing.

The normal breaker point gap is 0.023 inch at full separation. However, the fixed running spark advance of 18° is regulated by the point opening, and thus a slight deviation from 0.023 may occur when obtaining an accurate spark advance with a timing light.

With reference to *Fig's. 10 and 11*, adjust breaker point gap as follows, and then proceed as per instructions in *Timing* paragraphs.

1. Turn engine over by means of the starter sheave until breaker arm push pin is at the high point of the striker plate (maximum point opening).
2. Loosen contact support plate lockscrew very slightly (just enough so that plate can be moved).
3. Place a 0.023 inch feeler gauge between the points.
4. Insert screw driver in adjusting slot and open or close points as required, until a slight drag is felt while sliding feeler gauge between points.
5. Securely tighten lockscrew and recheck point gap.

## TIMING

### MAGNETO or BATTERY IGNITION

The fixed running spark advance of 18° is regulated by the breaker point opening and reasonably accurate timing is obtained by simply setting the breaker point gap to 0.023 inch, as explained in "Breaker Point Adjustment". However, static timing with a continuity light, as illustrated in *Fig. 12*, is more accurate and advisable. The timing light is Wisconsin Motor part number DF-81-S1.

A pointer is located in the crankcase, just to the left

of the breaker box, to visibly check the advance timing mark on the rim face of the flywheel.

### STATIC TIMING PROCEDURE: See *Fig. 12*.

1. Disconnect coil primary wire at bottom of breaker box. Remove breaker box cover.
2. Timing mark on flywheel can be observed thru the hole in back plate of flywheel shroud, just to the left of the breaker box.

Since breaker arm operates at half engine speed; line up flywheel timing mark and pointer, with engine on compression stroke. The compression stroke can be determined by turning starter sheave in a clockwise direction and watch for breaker arm movement by push pin in breaker box.

3. Connect one lead wire of the timing light DF-81-S1 to ground and the other to the terminal stud at bottom of breaker box. (With points closed, the timing light will be on).
4. Slightly loosen lockscrew on contact support plate (just enough so that plate can be moved).
5. Insert a screw driver into support plate adjusting slot and close points so that light is on, then turn screw driver slowly in the opposite direction until the light just goes out. Retain points in this position and securely tighten lockscrew.
6. As a final check; turn flywheel counter-clockwise until timing light is on. Then, slowly rotate flywheel clockwise, and stop immediately when light goes out. At this point, mark on flywheel should be in line with timing pointer in crankcase.
7. Assemble coil primary wire to terminal stud and mount breaker box cover.

## MAGNETO SERVICE INSTRUCTIONS

If engine will not start or if it is hard to start and does not run properly, make the following tests to see if the magneto is at fault:

1. Check carefully for loose, corroded, broken or worn ignition wires.
2. Check the spark; refer to "Ignition Spark" and "Spark Plug" paragraphs.
3. Check points for cleaning, alignment and adjustment. If badly worn or corroded, points and condenser should be replaced. Refer to "Breaker Points".
4. Magneto coil replacement should be done by a competent mechanic using adequate test equipment. The coil can be tested in the following manner and without removing the flywheel:

Position flywheel so keyway is at the bottom.

Remove the coil primary lead from the terminal connection at the breaker box and the spark plug lead from the plug. The coil can now be tested using the primary lead, the high tension lead, and the engine block as the ground connection.




Fig. 12

293065C

It is recommended that a new coil be selected from stock and used as a master coil to calibrate the tester. If the tester is set up with a "good-bad" range or "variable spark discharge gap", it can be used with whatever primary input is required to bring it into the desired range.

If the coil does not test to specification, the flywheel will have to be removed to replace the coil.

The high tension wire can be removed from the coil by twisting the wire in a counterclockwise direction.

## ELECTRICAL EQUIPMENT

### ELECTRICAL WIRING CIRCUITS

**NOTE:** Beginning with engine serial No. 3981420 the standard wiring circuits of all 12 volt electrical equipment for Models S-10D and S-12D is *negative ground polarity*, instead of the previously furnished positive ground. Model S-14D, always was *negative ground*.

The wiring diagram, Fig. 13 (magneto ignition), illustrates a *negative ground* circuit. If polarity of




Fig. 13, WIRING DIAGRAM (with Magneto Ignition)

motor-generator is for a positive ground circuit, terminal connections at ammeter and battery are just reversed from those illustrated.




Fig. 14, WIRING DIAGRAM (with Battery Ignition)

*Battery ignition engines*, are wired in accordance with Fig. 14. This type ignition system has always been wired *negative ground*. Battery is not furnished by Wisconsin Motor Corporation.

### MOTOR-GENERATOR OPERATING INSTRUCTIONS

The combination *motor-generator* functions as a cranking motor when the *starting switch* is closed. When the switch is open and the engine is running, the unit will function as a generator. The generator output and circuit voltage for the various battery and operating requirements are controlled by a *current-voltage regulator* mounted to the generator.

The total electrical output of this *12 volt* combination motor-generator is *12 amperes*. However, all of the current is not taken off of a single terminal. There are *two terminals* on the current-voltage regulator, illustrated in Fig. 15, for distributing the generator output. One terminal is marked '*BAT*' and a wire is connected from it to the battery, thru an *ammeter*. The other terminal marked '*L*' is for a battery ignition system, if applicable, and for operating lights or any other customer accessory. For a continuous load, not more than *5 or 6 amps* should be taken from this terminal if engine has magneto ignition. With battery ignition, maximum draw should be *3 or 4 amps*, since *2 amps* is required for the ignition system. Current from the '*L*'




Fig. 15, MOTOR-GENERATOR REGULATOR WIRING

terminal is continuous and is not affected by the regulator windings. Whereas, the current to the '*BAT*' terminal goes thru the regulator windings and is controlled to keep the battery charged.

To check if the generator is charging, it is only necessary to observe the ammeter that is connected in the battery circuit. If it shows a charge, the system is functioning properly. If it shows a discharge, remove the load connected to the '*L*' terminal until the battery current is restored and the ammeter does register a charge.

Periodically inspect motor-generator and external wiring for conditions which may affect its operation.

Bearings are *pre-lubricated*, therefore no external oiling is required.

Inspect the brushes for wear, approximately every *200* hours of operation. If they are worn to less than half their original length, they should be replaced.

### HIGH TEMPERATURE SAFETY SWITCH

As a safety precaution against overheating, engines can be equipped with a high temperature switch. The switch is mounted to a cylinder head bolt, opposite the spark plug at the take-off end.

When cylinder head temperature becomes critically high, the safety switch will automatically stop the engine by shorting out the ignition system. A waiting period of about *10 minutes* will be required before the switch has cooled off sufficiently to re-start the engine. An overheated engine will score the cylinder walls, burn out connecting rod and crankshaft bearings, also warp piston and valves. The cause of the overheating condition will have to be remedied before the engine is re-started. See *Engine Overheats* paragraph in *Troubles, Causes and Remedies* section.

A *service kit* is available for installation on engines in the field. Refer to *parts section* in rear of manual for mounting location and illustrated parts list.

### SPARK PLUG

The spark plug should be removed periodically, cleaned and re-gapped. The width of the gap between the points of the two electrodes must be very carefully and precisely set, because incorrect settings will have an adverse affect on engine operation. Check spark plug gap with a wire type gauge and regap as shown in Fig. 16.




Fig. 16

27779C



Spark plug gap - 0.030 of an inch.

Use a new spark plug at the beginning of a new season. Replacement plug must be of the correct heat range, like Champion No. D-16J, AC No. C86 commercial or equal. Thread size is 18mm.

Use a new gasket when mounting either old or new plug and thoroughly clean threads in cylinderhead before installation. Tighten spark plug 28 to 30 foot pounds torque. If torque wrench is not available, tighten plug until it begins to seat on the gasket, then turn 1/2 to 3/4 of a turn more.

## CLUTCH AND REDUCTION GEARS

### CLUTCH TAKE-OFF (Fig. 17)

The clutch in the take-off assembly, available on this model of engine, is of the multiple disc type running in oil. Use the same grade of oil in clutch housing as is used in the engine crankcase, and fill to the height of the oil level plug, through the inspection plate opening; about 1 pint of oil is required.




Fig. 17

296109C





Fig. 18

296110C



### REDUCTION GEARS (Fig. 18 and Fig. 19)

Reduction gears are furnished in several different ratios, some with spur gears, others with chains. All are of the same general design, except that some are furnished with clutches, others without.

*Use same grade oil as used in engine crankcase.*

Several plugs are furnished so that lubrication may be properly taken care of regardless of the position of installation. There will always be one plug on top to be used for filling oil, one plug below for draining oil, and a plug on the side, slightly above bottom, for the oil level. The oil should always be filled when the engine is at rest. When oil becomes dirty it should be drained while the engine is hot, and fresh oil added. The frequency at which these oil changes should be made depends entirely on the kind of service in which these gears are used, but even with light service;

*Change oil at least every 500 hours of operation.*

Add sufficient oil between changes to keep oil up to the oil level plug. The oil capacity for the *reduction unit* shown in Fig. 18 is 2/3 pint, and for the *clutch reduction unit*, Fig. 19, 1 pint.

### CLUTCH ADJUSTMENT (Fig. 20)

If the clutch begins to slip, it should be readjusted to prevent it from becoming overheated and damaged. The clutch in the *clutch take-off* and *clutch reduction units* is adjusted by first removing the clutch inspection plate which will expose the notched *adjusting ring*. Release the *clutch*, by pushing the *engaging lever* forward (toward engine).

Turn engine over by means of the rope starter sheave, until the *clutch adjustment lock* is visible thru the inspection opening of the housing. Loosen *adjustment*




Fig. 20 244949C

lockscrew, one full turn. On *take-off units*, the lock-screw is accessible thru the pipe plug hole behind the inspection opening.

Keep clutch from turning by holding rope starter sheave firmly in place with the left hand. Then, by means of a screw driver, turn *adjusting ring* one notch at a time in a clockwise direction, until a definite pressure is felt on the clutch lever when engaging. When properly adjusted, the clutch will engage with a slight snap. Tighten *lockscrew* and mount inspection cover. Be sure cover gasket is in good condition.

## RESTORING COMPRESSION

On a new engine, or one which has been out of operation for some time, the oil may have drained off the cylinder so that compression will be weak. This may cause difficulty in starting. To remedy this condition, remove the spark plug and pour about a fluid ounce of crankcase oil through the spark plug hole. Turn engine over several times with the rope starter to distribute oil over the cylinder walls. Then mount spark plug and compression should be satisfactory.

## WINTER STORAGE

To protect the cylinder, piston, rings, valves, and keep them from rusting and sticking, a half and half mixture of kerosene and good engine oil, (the same kind of oil as used in the crankcase of the engine), should be injected into the pipe tap opening on the air cleaner bracket while the engine is warm and running at moderate speed. About a quarter of a pint is necessary, or enough so that a heavy bluish smoke will appear at the exhaust. The ignition switch should then be shut off and the engine stopped. This fogging operation will leave a coating of oil on the above mentioned parts, protecting them from the atmosphere. After the engine has stopped, disconnect the spark plug cable and turn engine over slowly until the fly-wheel key or take-off shaft keyway is up, or in the 12 o'clock position and on compression stroke. Both valves will then be closed and the piston will be on top in the cylinder bore. This will minimize rusting of

the cylinder bore and help in retaining the oil fog previously injected into the engine.

Drain crankcase oil while engine is warm.

Drain fuel lines, carburetor, fuel pump and tank, to prevent lead and gum sediment from interfering with future operation. Gasoline fumes from gradual evaporation is a dangerous *fire hazard*.

The air cleaner and filter element should be thoroughly cleaned. Tape or otherwise seal off the exhaust and air cleaner openings for the duration of the storage period.

The outside of the engine, including the cooling fins on the cylinder and head, should be thoroughly cleaned of all dirt and other deposits. All exposed unpainted metal parts should be coated with grease or heavy oil.

Before adding new crankcase oil the next season, drain base of condensation which may have accumulated during the storage period.

*Fill crankcase with a good quality of oil to the high level point, before starting engine. Do not use any oil heavier than S.A.E. No. 30.*

Use a new spark plug at the beginning of the next season, especially if the engine has given considerable service.

*It is highly recommended that machines be stored inside a building through the winter. If this is not possible, the engine should be protected from snow and ice by a proper covering.*

## TROUBLES CAUSES AND REMEDIES

Three prime requisites are essential to starting and maintaining satisfactory operation of gasoline engines. They are:

1. *A proper fuel mixture* in the cylinder.
2. *Good compression* in the cylinder.
3. *Good spark, properly timed*, to ignite the mixture.

If all three of these conditions do not exist the engine cannot be started. There are other factors which contribute to hard starting; such as too heavy a load for the engine to turn over at low starting speed, a long exhaust pipe with high back pressure, etc. These conditions may affect starting, but do not necessarily mean the engine is improperly adjusted.

As a guide to locating any difficulties which might arise the following causes are listed under the three headings: *Fuel Mixture, Compression, and Ignition*. In each case the causes of trouble are given in the order in which they are most apt to occur.

## STARTING DIFFICULTIES

### FUEL MIXTURE

No fuel in tank or fuel shut-off valve closed.

Fuel pump diaphragm worn out or damaged.

Carburetor not choked sufficiently, especially if engine is cold. See *'Starting Procedure'*, Page 9.

Water, dirt, or gum in gasoline interfering with free flow of fuel to carburetor.

Poor grade or stale gasoline that will not vaporize sufficiently to form the proper fuel mixture.

Carburetor flooded, caused by too much choking especially if engine is hot. See *'Starting Procedure'*.

Dirt or gum holding float needle valve in carburetor open. This condition should be indicated if fuel continues to drip from carburetor with engine standing idle. Often tapping the float chamber of the carburetor very lightly with the handle of a screw driver or similar tool will remedy this trouble. Do not strike carburetor with any metal tool.

If due to flooding, too much fuel entered the cylinder in attempting to start the engine, the mixture will most likely be too rich to burn. In that case the spark plug should be removed and the engine turned over several times with the starting sheave, so the rich mixture will be blown out through the spark plug hole. The choke must be left open during this procedure. Spark plug should be dried off, assembled, and starting tried again.

## COMPRESSION

Beginning with engine Serial No. 4225490, these models of engines were provided with an *automatic compression release*, so that the normal method of detecting faulty compression, by the resistance encountered when turning the engine over on the compression stroke, no longer holds true.

Check the following for suspected lack of compression, if the *fuel* and *ignition systems* are not the cause of starting difficulties and loss of power.

Cylinder dry due to engine having been out of use. See *'Restoring Compression'*, Page 16.

Loose or broken spark plug. In this case a hissing noise will be heard in cranking engine due to escaping gas mixture on compression stroke.

Damaged cylinder head gasket or loose cylinder head. This will likewise cause hissing noise on compression stroke.

Valve tappets with insufficient clearance under valve stems. See *'Tappet Adjustment'*, Page 24.

If correcting the above conditions does not remedy the situation, it will be necessary to partially dismantle the engine and check for:

Valve stuck open due to carbon or gum on valve stem. To clean valve stems, see *'Valves and Seat Insert'*, Page 19.

Piston rings stuck in piston due to carbon accumulation. This will require removing piston and connecting rod assembly, and cleaning parts. See *'Connecting Rod and Piston'*, Page 22.

Scored cylinder. This will require reboring the cyl-

inder and fittings with new piston and rings. If scored too severely an entirely new cylinder block may be necessary.

## IGNITION

See *'Ignition Spark'*, Page 11. No spark may also be attributed to the following:

Ignition wires disconnected from magneto, coil, spark plug or breaker box.

Broken ignition wires causing short circuits.

Spark plug cable wet or oil soaked.

Spark plug insulator broken. Plug wet or dirty.

Spark plug point gap wrong. See Page 15.

Breaker points pitted or fused.

Breaker arm sticking.

Condenser leaking or grounded.

Oil in breaker box. See *'Crankcase Breather'*, Page 11.

Spark timing wrong. See *'Timing'*, Page 12.

## ENGINE MISSES

Spark plug gap incorrect. See Page 15.

Worn and leaking ignition cable.

Weak spark. See *'Ignition Spark'*, Page 11.

Loose connections at ignition wires.

Breaker points pitted or worn.

Oil in breaker box. See *'Crankcase Breather'*, Page 11.

Water in gasoline.

Poor compression. See *'Compression'*, Page 17.

## ENGINE SURGES OR GALLOPS

Carburetor flooding.

Governor spring hooked into wrong hole in lever, or governor rod incorrectly adjusted. See *'Governor Adjustment'*, Page 25.

## ENGINE STOPS

Fuel tank empty. Water, dirt or gum in gasoline.

Gasoline vaporized in fuel lines due to excessive heat around engine (Vapor Lock). See *'Stopping Engine'*, Page 9.

Vapor lock in fuel lines or carburetor due to using winter gas (too volatile) in hot weather.

Air vent hole in fuel tank cap plugged. Engine scored or stuck due to lack of oil.

Ignition troubles. See *'Ignition'*, Page 17.

## ENGINE OVERHEATS

Crankcase oil supply low. Replenish immediately.

Ignition spark timed wrong. See *'Timing'*, Page 12.

Low grade of gasoline. Carbon in engine.

Engine overloaded.

Restricted cooling air circulation.

Part of air shroud removed from engine.

Dirt between cooling fins on cylinder head.

Engine operated in confined space where cooling air is continually recirculated.

Dirty or incorrect grade of crankcase oil.

Restricted exhaust.

Engine operated while detonating due to low octane gasoline or heavy load at low speed.

## ENGINE KNOCKS

Poor grade of gasoline or of low octane rating.

Engine operating under heavy load at low speed.

Carbon or lead deposits in cylinder head.

Spark advanced too far. See 'Timing', Page 12.

Loose or burnt out connecting rod bearing.

Engine overheated. See previous heading.

Worn or loose piston pin.

## ENGINE BACKFIRES THROUGH CARBURETOR

Water or dirt in gasoline, or poor grade of gasoline.

Sticky inlet valves. See 'Valves and Seat Insert', Page 19.

Overheated valves, or hot carbon particles in engine.

Engine cold.

## DISASSEMBLY AND REASSEMBLY OF ENGINE

Engine repairs should be made by an experienced mechanic. When disassembling the engine it is advisable to have several boxes available so that parts belonging to certain groups can be kept together. Capscrews of various lengths are used in the engine, therefore great care must be exercised in reassembly so that the correct screws are used in the proper places.

Tighten the capscrews of the cylinder head, gear cover, connecting rod, stator plate and the spark plug to the specified torque readings indicated in the paragraphs of reassembly, relative to these parts.

While the engine is partly or fully dismantled, all parts should be thoroughly cleaned. **Use all new gaskets** in reassembly and lubricate all bearing surfaces.

The following procedure is for complete disassembly of an engine. Instructions on reassembling are also given, as often it will not be necessary to disassemble the entire engine. As disassembly progresses, the order may be altered somewhat, as will be self-evident to the mechanic.

## TESTING OF REBUILT ENGINE

An engine that has been completely overhauled, such as having the cylinder rebored and fitted with new piston, rings and valves, should go through a thorough "run-in" period before any load is applied to it.

The engine should be started and allowed to run for about one-half hour, at about 1600 to 1800 R.P.M. without load. The R.P.M. should then be increased to engine operating speed, still without load, for an additional three and one-half to four hours.

The proper "running-in" of the engine will help to establish polished bearing surfaces and proper clearances between the various operating parts.

## DRAIN OIL FROM CRANKCASE BEFORE DISASSEMBLY

## ACCESSORIES

Remove muffler and disconnect ignition wire from spark plug. If engine is to be completely overhauled, remove all accessories.

On engines equipped with a combination *motor-generator*; disconnect wires and adjusting strap at the generator. Remove bracket and motor-generator from side of crankcase as a complete unit.

**Caution:** In reassembly, do not put too much tension on drive belt.

## FUEL TANK (Fig. 21)

Close fuel valve at tank and disconnect fuel line. Remove three nuts and washers which hold tank bracket to cylinder head studs. *Fuel tank* and *bracket* can then be removed as a complete unit.




Fig. 21

293064C

## CARBURETOR and AIR CLEANER (Fig. 22)

The carburetor and air cleaner should be removed both to facilitate working on the engine and to prevent damage to these parts. Unscrew wing nut and remove air cleaner. Be careful of oil in cleaner. Disconnect; breather line at inspection cover, throttle rod clip at governor lever and fuel line. Take out the two nuts holding carburetor flange to cylinder, and remove *carburetor - air cleaner bracket* as a complete unit.






Fig. 22 293052C

*In reassembly*; when attaching air cleaner bracket to flange on carburetor air horn, use new gasket and tighten the three mounting screws to **34 inch lbs. torque** (minimum).

#### STARTER SHEAVE and FLYWHEEL SHROUD (Fig. 23)

Remove *starter sheave* and *screen* by taking out the three screws and washers that mount to the flywheel.

Take off *top cover* and *cylinder side shroud*. Unhook governor spring and remove four screws holding flywheel shroud to back plate. *Flywheel shroud* can then be removed. Back plate can be taken off, only if necessary, after flywheel is removed.

#### CYLINDER HEAD and SPARK PLUG (Fig. 24)

Remove spark plug and take out the three cylinder head studs and five capscrews. After removal of cylinder head and gasket, clean out all carbon deposits from combustion chamber and dirt from between cooling fins.

*In reassembly*, use new cylinder head and spark plug gaskets. **Note:** Internal contour of cylinder head gaskets at inlet and exhaust valves are not the same. Mount gasket to cylinder block with the larger internal radius located at the inlet valve. See Fig. 24.

Apply a mixture of graphite and oil to the threads of the cylinder head studs and capscrews. **Torque** to **32 ft. lbs.** in three alternate stages: 16 ft. lbs., 24 ft. lbs. and finally 32 ft. lbs.

Leave spark plug off temporarily, for ease in turning engine over for remainder of assembly and for timing adjustments. When mounting spark plug, tighten **28 to 30 ft. lbs. torque**.




Fig. 23 293066C




Fig. 24 293067C




Fig. 25 293044C

#### VALVES and SEAT INSERTS (Fig's. 25, 26, 27)

Take off the combination valve inspection cover and breather assembly. By means of a standard automotive valve lifter, remove retainer locks and take out valves from top of cylinder block.

Clean out carbon and gum deposits from the valves,





Fig. 26

284070C



SPECIFICATIONS ARE FOR BOTH INLET AND EXHAUST

A - VALVE FACE ANGLE	45°	
B - SEAT INSERT ANGLE	45°	
C - GUIDE INSIDE DIAMETER	.312 - .313	
D - VALVE STEM DIAMETER	Inlet	.310 - .311
	Exh.	.308 - .309
MAXIMUM ALLOWABLE CLEARANCE BETWEEN C AND D	IN.	.005
	EXH.	.007

Fig. 27

seats, ports and guides. Replace valves that are badly burned, pitted or warped.

The *exhaust valve face* and *exhaust seat insert* are of *stellite* material. A positive type *valve rotator* is furnished as standard equipment on the exhaust valve only. Clean and inspect operation of rotator.

The inlet and exhaust *seat inserts* can be removed, when replacement becomes necessary, by means of Wisconsin Motor *DF-66-A* insert puller. See Fig. 26.

*Grinding of valves and seats* should be done by an authorized Wisconsin service station. See directory in rear of manual.

*Before grinding valves*, inspect valve guides for possible replacement. Refer to Fig. 28 for proper




Fig. 28

293045C

method of driving out guides, and see chart, Fig. 27, for valve, seat and guide specifications.

*After grinding*, lap valves in place until a uniform ring will show entirely around the face of the valve. Clean valves, and wash block thoroughly with a hot solution of soap and water. Wipe cylinder walls with clean lint free rags and light engine oil, especially if honing operation was also performed.

#### VALVE GUIDES (Fig. 28)

When valve stem clearance becomes excessive, the valve guides should be driven out, as illustrated in Fig. 28, and new guides pressed in place. Use Wisconsin Motor *DF-72* valve guide driver. In reassembly, press guides into valve ports using the same driver tool. Refer to Fig. 27 for clearance specifications and proper assembly.

#### FLYWHEEL (Fig's. 29 and 30)

*Caution:* If flywheel is to be removed it must be loosened at this time. **Do not** attempt to loosen flywheel after gear cover is removed. Striking the crankshaft, without support from gear cover, would inflict damages to the crankshaft, rod and piston.

Straighten tab of star lockwasher that is bent over on flat of flywheel nut. Place a 1-11/16" box or socket wrench on to flywheel nut and give the wrench a sharp blow with a soft hammer. **Do not remove nut**, simply unscrew it flush with end of shaft.

The flywheel is mounted to a taper on the crankshaft. Take a firm hold on the flywheel fins, pull outward and at the same time strike the end of the crankshaft with a babbitt hammer. The flywheel will slide off the taper of the crankshaft. Do not use a hard hammer as it may ruin the crankshaft and bearings.

*Loosen flywheel but do not remove:* It is necessary that the flywheel be left on to support crankshaft dur-




Fig. 29

293061C




Fig. 30

293042C

ing removal of gear cover and connecting rod, and prevent damaging oil seal in stator plate. *Take flywheel off after piston and connecting rod are removed.*

*In reassembly*, mount flywheel immediately after crankshaft is mounted; be sure *woodruff key is in position* on crankshaft and is properly lined up with keyway in flywheel hub. *Do not* drive flywheel on to taper of crankshaft. Place a short piece of pipe against hub of flywheel and tap end of pipe with a soft hammer to seat flywheel on to taper. Mount star washer with tab inserted in flywheel keyway. Assemble nut and tighten only enough to hold flywheel in place. Then, *after end play is set* (see *End Play paragraph*) tighten flywheel nut by placing wrench on nut and giving handle of wrench several sharp blows with a soft hammer. Bend one tab of star washer over flat on flywheel nut.

### GEAR COVER (Fig's. 31 and 32)

Remove gear capscrews and take off governor lever. Tap the two *dowel pins* with a hammer, from crank-




Fig. 31

293062C




Fig. 32

case side, and gear cover will break loose from crankcase. *Caution:* Steel ball for camshaft end thrust will probably fall out when gear cover is removed. Take thrust spring out from end of camshaft to prevent it from becoming lost.

*In reassembly*; insert thrust spring into end of camshaft and lubricate bearings, gear train and tappets.

Tap dowel pins into gear cover until they extend about 1/8" past the flange face. Place a dab of low melting grease into hole of gear cover to retain camshaft thrust spring ball in place. Lubricate lip of oil seal and add a light film of oil to gear cover face to hold gasket in place.

Place *sleeve tool* Fig. 32. in oil seal, drop steel ball into grease filled hole and assemble gear cover by tapping in place with a soft hammer.

*Caution:* Be sure *timing marks on crankshaft and camshaft gear, Fig. 41, remain correctly mated when end of camshaft is pressed into bearing hole of gear cover.*

*Note:* Governor yoke must straddle governor shaft extension and bear against thrust sleeve.

Remove oil seal sleeve, tighten gear cover capscrews to 22 ft. lbs. torque and hammer dowel pins in place. Mount governor lever.

### GOVERNOR FLYWEIGHT ASSEMBLY (Fig's. 33, 34)

The governor gear and flyweight assembly rotates on




Fig. 33

293043C-1




Fig. 35

293046C




Fig. 34

293047C

a stationary pin pressed into the crankcase and is held in place with a snap ring.

**To disassemble:** Spread flyweights apart and remove governor thrust sleeve. By means of a snap ring pliers, snap ring can be removed and the gear-flyweights slipped off the shaft.

**Reassembly** is made in reverse order. Maintain a clearance of .003 to .005" between gear hub and face of governor shaft boss in crankcase, see Fig. 34. This end play can be adjusted by tapping the governor shaft in either direction. Clearance between shaft and gear is .0005 to .002". When clearance becomes .005", replace worn parts.

### CONNECTING ROD and PISTON (Fig's. 35, 36, 37)

By means of a 1/2" socket wrench, loosen and remove hex nuts from connecting rod bolts. Oil dipper will come off when nuts are removed. Then, by tapping the ends of the bolts lightly, the connecting rod cap will break free from the bolts.

Scrape off all carbon deposits that might interfere with




Fig. 36

293048C

removal of piston from cylinder. Turn crankshaft until piston is at top, then push connecting rod and piston assembly upward and out thru top of cylinder. Be careful not to mar the crank pin by allowing the rod bolts to strike or scrape across it.

The connecting rod has a removable shell bearing and care should be taken *in reassembly* to mount bearing properly. The cap should be assembled to the rod so that the *locating lug* of both bearing halves are on the same side, see Fig. 36. Refer to chart, Fig. 37, for clearance between shell bearing and crank pin.

The piston skirt is *cam-ground* to an elliptical con-

PISTON TO CYLINDER AT PISTON SKIRT THRUST FACES	MODELS S-10D, S-12D .0025 to .003"	MODEL S-14D .0025 to .004"
PISTON RING GAP		.010 to .020"
PISTON RING SIDE CLEARANCE IN GROOVES	TOP RING	.002 to .004"
	2nd RING	.002 to .004"
	OIL RING	.0015 to .0035"
Connecting Rod to Crank Pin - Side Clearance		.004 to .013"
Connecting Rod Shell Bearing to Crank Pin		.0005 to .0015"
PISTON PIN TO CONNECTING ROD BUSHING		.0005 to .0011"
PISTON PIN TO PISTON		.0000 to .0008" tight




Fig. 37

tour. Clearance between the piston and cylinder must be measured at the bottom of the piston skirt thrust face. Refer to Chart, Fig. 37, for proper clearance. The thrust faces on the piston skirt are 90° from the axis of the piston pin hole.

*In reassembly;* use a ring compressor and stagger the piston ring gaps 90° apart around the piston. Oil the piston, rings, wrist pin, rod bearings and cylinder walls before assembly.

*Note:* Mount piston and rod assembly with the *stamped number* on the connecting rod bolt boss facing toward the open end of the crankcase. Assemble connecting rod cap in like manner so that the two numbers are on the identical side. Turn crankshaft to lower end of stroke and tap piston down until rod contacts crank pin. Mount dipper so that cap nuts are accessible from open end of crankcase. Tighten connecting rod nuts to 22 foot pounds torque.

### PISTON RINGS (Fig's. 38 and 39)

If a ring expander tool is not available, install rings by placing the open end of the ring on piston first, as shown in Fig. 38. Install bottom ring first and work up to the head of piston, installing top ring last. Spread ring only far enough to slip over piston and into correct groove, being careful not to distort ring. A *pit mark*, or the word *'top'* is stamped on the rings, to indicate the correct placement of the rings on the piston: Scraper ring must be mounted with scraper edge down, otherwise oil pumping and excessive oil consumption will result.




Fig. 38

71152C




Fig. 39

296112C

### CYLINDER BLOCK

Clean all dirt and foreign deposits from between the cylinder block fins.

The block does not have to be removed unless the cylinder bore is worn more than .005 inch oversize. The block should then be reground and fitted with oversize piston and rings. This work should be done at an authorized 'Wisconsin Service Station'.

*In reassembly:* tighten the four cylinder block mounting nuts, 40 to 50 foot pounds torque. The capscrew in valve spring compartment should be tightened to 32 foot pounds torque.

### CAMSHAFT and VALVE TAPPETS (Fig. 40) TIMING MARKS (Fig. 41)

To prevent tappets from falling out and becoming damaged when camshaft is removed, turn crankcase over on its side as shown in Fig. 40. Push tappets inward to clear cam lobes and remove camshaft.




Fig. 40

293059C-






Fig. 41

293041C-1

Remove tappets; check face for scuffing and inspect body for wear. Body diameter of  $.6245/.6235"$  has a clearance of  $.0005$  to  $.0025"$  in guide hole.

*In reassembly:* Tappets must be inserted in crankcase before camshaft is assembled. Mount camshaft so that *timing mark* on cam gear matches up with *marked gear tooth* on crankshaft gear. See Fig. 41. If valve timing is off, engine will not function properly or may not run at all. Be sure *thrust spring* is in place in end of camshaft, before mounting gear cover.

#### TAPPET ADJUSTMENT (Fig. 42)

*Tappet adjustment* can be made immediately after assembling the valves, springs and locks, see Fig. 42. With the tappets in their lowest position and the engine cold, the clearance should be:

inlet -  $.007$  inch  
exhaust -  $.016$  inch

*Caution:* Be sure exhaust tappet is not riding on compression release spoiler cam.

To check tappet clearance on an assembled engine; turn crankshaft so that take-off or flywheel keyways are in a 12 o'clock position, and on compression stroke. Observe position of valve stems in the inspection compartment. Both valves should be in their lowest position (closed); proceed to check clearance.




Fig. 42

293060C




Fig. 43

311748C

#### COMPRESSION RELEASE (Fig. 43)

The *automatic compression release* is incorporated with the engine camshaft, and with proper engine maintenance should operate trouble free, with a minimum of wear.

While cranking engine, a *spoiler cam* holds the exhaust valve slightly open thru a portion of the compression stroke. This condition reduces the compression pressure, allowing the engine to be turned over faster and with less effort. After the engine starts and speed reaches 650 R.P.M., the *flyweight* places spoiler cam in an inoperative position and normal compression is returned to combustion chamber.

#### BREAKER PUSH PIN and BUSHING (Fig. 44)

*Push pin* for breaker arm should be removed, inspected for wear and replaced if necessary. *In reassembly:* Mount *assist spring* under head of push pin and insert pin assembly into guide hole, with *spherical end* of pin toward camshaft striker plate, see Fig. 44.

If clearance between new push pin and bushing is excessive, replace bushing. Ream I. D. of bushing  $.2785$  to  $.2790$  inches after pressing in place. Mount bushing to crankcase with LOCTITE if necessary.




Fig. 44




Fig. 45

293063C

### CRANKSHAFT (Fig. 45)

Take off flywheel nut and remove flywheel. Knock out woodruff key and pull crankshaft out from open end of crankcase.

*In reassembly;* mount flywheel after crankshaft is assembled, and hand tighten flywheel nut. Flywheel will support crankshaft for mounting of connecting rod and piston. Flywheel nut is tightened after gear cover is mounted, and previous to checking end play.

### STATOR PLATE and END PLAY (Fig's. 46, 47)

The stator plate functions as an adapter for the magneto coil as well as a front bearing support. Since the crankshaft end play is adjusted by means of the stator plate gaskets, it is advisable not to remove the plate unless replacement is necessary.

To remove stator plate, take out four capscrews and tap plate from inside crankcase with a wooden hammer handle. *In reassembly:* Use new gaskets having the same total thickness as those removed. Torque stator plate capscrews to 18 ft./lbs.

*End play* is checked after crankshaft, gear cover and flywheel are mounted. The end play should be .001 to .004 inch with engine cold, and can be determined as illustrated in Fig. 47. Wedge a lever between the fly-




Fig. 46

293049C




Fig. 47

284080C

wheel and crankcase, and move the crankshaft forward and backward against a dial indicator. If there is too much end play, a corresponding thickness of gasket will have to be removed from behind stator plate. Not enough end play and gasket will have to be added.

If new tapered crankshaft main bearings are installed, seat bearings by alternately striking each end of the crankshaft several sharp blows with a lead hammer. Then proceed to check crankshaft end play.

*After end play is set;* refer to flywheel reassembly paragraphs, for final instructions on tightening of flywheel nut.

## GOVERNOR

### OPERATION

Two flyweights are hinged to lugs on the governor gear. Hardened fingers on the flyweights bear against a thrust sleeve, moving it back and forth as the flyweights move in or out. The motion of the thrust sleeve is transmitted through a yoke connected to the governor lever, which in turn is connected to the carburetor throttle. A spring connected to the governor lever tends to hold the governor flyweights to their inner position, also to hold the carburetor throttle open. As the engine speed increases, centrifugal force from the flyweights acts against the spring and closes the throttle to a point where the engine speed will be maintained practically constant under varying load conditions. This speed can be varied to suit conditions by adjusting the governor spring tension.

### GOVERNOR ADJUSTMENT (Fig. 48)

The governor rod connection to the carburetor must be very carefully adjusted for length, otherwise the governor will not function properly and may cause the engine to surge badly. With the engine at rest, the governor spring will keep the flyweights in, and the control rod must be of such length as to hold the carburetor throttle wide open at that point.

With the control rod disconnected from the governor lever, as illustrated in Fig. 48, push the rod toward the carburetor as far as it will go. This will put the carburetor throttle lever in a wide open position. The




Fig. 48 293050C

governor lever should then be extended as far as possible in the same direction. Holding both parts in the above position, the rod should be screwed in or out of the *swivel block* on the carburetor, until the *bent end* of the rod will register with *hole* in lever.

Snap control rod clip in place and tighten *locknut* against swivel block on carburetor throttle lever.

### CORRECT ENGINE SPEED (Fig. 49)


*Engine speed* is adjusted by hooking governor spring in correct hole of governor lever, and then regulating spring tension by means of an adjusting screw. The governor lever has 7 holes for the governor spring, with the No. 1 hole closest to the fulcrum shaft.

**Caution:** Beginning with engine serial No. 5,675,598 the *WALBRO* carburetor is standard equipment, with the *ZENITH* carburetor optionally used. When readjusting engine speed, use chart in *Fig. 49* relative to the Carburetor Type.

**Note:** Two different length adjusting screws are required for the complete range of operating speeds (see chart).

The governor lever chart in *Fig. 49*, shows the *load* and *no load* speeds and the corresponding governor spring hole. After hooking spring into the lever hole relative to the desired *load speed*, run the engine without load and regulate the spring tension by means of the *adjusting screw* until the required *no load* speed is obtained. The governor spring will have to be disconnected from governor lever each time screw is turned in or out.

A tachometer or revolution counter should be used against the crankshaft to check speed while adjusting the governor spring tension. The engine speed without load will vary from 75 to 180 revolutions per minute higher than the speed with load. For instance; if the engine is to operate at 3400 R.P.M. under full load, the speed with no load will be 3520 R.P.M. Refer to the governor lever chart, *Fig. 49* for the variation between load speed and no load (high idle) speed.



Use 3-15/16" long Adjusting Screw			Use 3-5/8" long Adjusting Screw		
LOAD R.P.M.	NO LOAD R.P.M.	HOLE NO.	LOAD R.P.M.	NO LOAD R.P.M.	HOLE NO.
<b>'ZENITH' CARBURETOR</b>					
1600	1760	1	2600	2720	4
1800	1875	2	2700	2810	4
1900	2040	2	2800	2940	5
2000	2120	2	2900	3010	5
2100	2260	3	3000	3150	6
2200	2340	3	3100	3230	6
2300	2400	3	3200	3360	7
2400	2580	4	3300	3455	7
2500	2650	4	3400	3520	7
			3500	3590	7
			3600	3680	7
<b>'WALBRO' CARBURETOR</b>					
1600	1680	1	2600	2735	4
1800	1875	2	2700	2820	5
1900	1985	2	2800	2920	5
2000	2090	2	2900	3020	5
2100	2190	2	3000	3130	5
2200	2305	3	3100	3215	5
2300	2395	3	3200	3350	6
2400	2550	4	3300	3430	6
2500	2630	4	3400	3520	6
			3500	3605	6
			3600	3695	6

Fig. 49




# REPAIR PARTS LIST

READ THESE INSTRUCTIONS BEFORE ORDERING PARTS

The MODEL, SPECIFICATION and SERIAL NUMBERS of your engine, shown on the name plate prominently located on the engine, MUST BE GIVEN WHEN ORDERING PARTS.

COPY THE ABOVE SPECIFIED INFORMATION INTO THE SPACES PROVIDED BELOW  
SO THAT IT WILL BE AVAILABLE TO YOU WHEN ORDERING PARTS.

MODEL	<input type="text"/>	SERIAL NO.	<input type="text"/>
SIZE	<input type="text"/>	R.P.M.	<input type="text"/>
		SPEC. NO.	<input type="text"/>



TO INSURE PROMPT AND ACCURATE SERVICE, THE FOLLOWING  
INFORMATION MUST ALSO BE GIVEN.

1. State exactly, quantity of each part and part number.
2. State definitely, whether parts are to be shipped by express, freight or parcel post.
3. State exact mailing address.

## SERVICE FACILITIES

Wisconsin Engine Distributors and Service Centers, located throughout the U.S. and foreign countries, have been carefully selected in order to assure complete and efficient repair and inspection service to owners of Wisconsin Engines. These service centers, equipped and staffed for complete engine repair also stock parts to facilitate immediate delivery for all Wisconsin Air Cooled Engine Models. Order parts from the Distributor or Service Center in your locality — **DO NOT** order parts from WIS-CON TOTAL POWER.

# S10D-S12D-S14D ENGINES

## Important Notice

The manuals contained in this computer file are reproductions from the "Wisconsin Engine" counter catalog, part number "S236". This manual was last produced in the mid 1980's.


As with any printed data, the information contained in these manuals may not be the most up-to-date available. It is provided as a convenience to our customers and all information should be verified before making repairs to an engine or component.

## **SERVICE FACILITIES**

**WISCONSIN MOTORS, L.L.C.** Distributors and Service Centers, located throughout the U.S. and foreign countries, have been carefully selected to insure complete and efficient repair and inspection services to owners of **WISCONSIN MOTORS** Engines. These service centers, equipped and staffed for complete engine repair, also stock engines parts to facilitate immediate delivery for the complete line of **WISCONSIN MOTORS** Engines.

Order parts from the **WISCONSIN MOTORS, L.L.C.** Distributor or Service Center in your locality. Refer to the Yellow Pages of the Telephone Directory under **ENGINES**, or visit our website, [www.wisconsinmotors.com](http://www.wisconsinmotors.com) to locate a distributor in your area. You can also call Wisconsin Motors toll free, 800-932-2858.

The **MODEL**, **SPECIFICATION** and **SERIAL NUMBER** of your engine must be given when ordering parts. The **MODEL**, **SPECIFICATION** and **SERIAL NUMBER** are on the engine nameplate.




**Wisconsin  
Motors, LLC**

Sales Office

2020 Fletcher Creek Drive - Memphis, TN 38133

Phone (901) 371-0353 Toll Free 800-932-2858

[www.wisconsinmotors.com](http://www.wisconsinmotors.com)




**CRANKCASE, CYLINDER HEAD, BLOCK, CARBURETOR and AIR CLEANER GROUP**

Parts are identified by reference number. See parts list for correct part number.

297769C-1


PARTS FOR ENGINE MODELS S-10D AND S-12D



GEAR COVER, CRANKSHAFT, PISTON, CONNECTING ROD and FUEL PUMP GROUP


Parts are identified by reference number. See parts list for correct part number.

297763C-1



**VALVES and CAMSHAFT GROUP**


297764C-1



**GOVERNOR ASSEMBLY**


297766C

Parts are identified by reference number. See parts list for correct part number.




**AIR SHROUDING and FUEL TANK GROUP**

Parts are identified by reference number. See parts list for correct part number.




**STATOR PLATE and FLYWHEEL GROUP**

297767C-1



**Ref. No. 237, BREAKER ASSEMBLY**


297768C-1




**Ref. No. 191, GASKET SET**

Parts are identified by reference number. See parts list for correct part number.

**LFA 100 Walbro Carburetor Assembly and LAA 138 Air Cleaner Assembly**  
For Models S12D and S14D Beginning with engine serial number 5,675,598.



**SERVICE LIST** of parts related to this change.



Ref. No.	Part Number	Description	No. Req.		Net Wt.	
			Req.	Lb	Oz	
81	LF 146	ADAPTER, carburetor .....	1		2	
82	LK 30	HOSE CLAMP, fuel line .....	2		1	
83	LL 178-19	FUEL LINE .....	1		3	
84	LL 201	BREATHER TUBE .....	1		3	
85	LO 194 A	ELEMENT, air cleaner .....	1		6	
86	LO 194 F	HOUSING, air cleaner .....	1		12	
87	LO 194 H	ADAPTER PLATE, air cleaner .....	1		6	
88	PD 147	WING NUT, air cleaner mounting .....	1		1	
89	PE 14	LOCKWASHER, No. 10 spring lock For air cleaner adapter plate .....	4		1	
90	PH 14 D	WASHER, 5/16" plain steel For carburetor and adapter mounting ....	4		1	
91	QC 12 A	GASKET, carburetor and adapter mtg. ..	2		1	
92	QD 860	GASKET, air cleaner adapter plate ....	1		1	
93	RF 1439	ELBOW, in carburetor for fuel line .....	1		1	
94	SD 308	DECAL, air cleaner instruction .....	1		1	
95	XA 7	SCREW, 10-32 x 3/8 long, round head For air cleaner mounting .....	4		1	
96	XD 16 B	SCREW, 5/16-18 x 7/8 hex hd., grade 5 For carburetor and adapter mounting ....	4		1	

**NOTE:** Two other parts affected by this change are in the basic engine **Parts List**.  
Ref. No. 178 **THROTTLE ROD** (PI 228)  
Ref. No. 210 **FLYWHEEL AIR SHROUD** (SE 337, SE 337 A)

Ref. No.	Part Number	Description	No. Req.		Net Wt.	
			Req.	Lb	Oz	
	<b>LAA 138</b>	<b>AIR CLEANER ASSEMBLY</b> Consisting of: Ref. No's. 84, 85, 86, 87, 88, 89, 92, 94, 95				
	<b>LFA 100</b>	<b>CARBURETOR ASSEMBLY</b> Consisting of: Ref. No's. 80, 81, 90, 91, 93, 96				
<b>80</b>	<b>L 106 A S1</b>	<b>CARBURETOR</b> , adjustable jet type .....	1	1		
		WALBRO No. <b>LMH 18</b> L 106 S1 (LMH 16) fixed jet carburetor replaced by L 106 A S1, interchangeable.				
		<b>LQ 54 A Repair Kit</b> for L 106 A S1, L 106 S1 LQ 54 Repair Kit, replaced by LQ 54 A.	1		6	
		<b>Q 46 Gasket Set</b> for L 106 A S1, L 106 S1	1		1	
		Refer to Walbro Carburetor Bulletin in back section of manual for Service Instructions - Parts List.				
		<b>NOTE:</b> For S12D, S14D engines previous to Serial #5,675,598 use <b>LTA 100</b> Carburetor and Air Cleaner-Conversion Kit for replacement of L 86 C, L 86 D, L 95, L 95 A Zenith carburetors.				

Order parts from nearest Wisconsin Distributor or Service Center.



# PARTS LIST FOR STANDARD MAGNETO IGNITION ENGINES, AND BATTERY IGNITION

## Models S-10D, S-12D and S-14D




THE FOLLOWING ARE NON-INTERCHANGEABLE PARTS BETWEEN THE ABOVE ENGINE MODELS

REF. NO.	PART NUMBER			DESCRIPTION	NO. REQ.	NET WEIGHT	
	MODEL S-10D	MODEL S-12D	MODEL S-14D			LBS.	OZ.
101	AA-109-S1 3-1/4" Bore	AA-108-S1 3-1/2" Bore	AA-112-S1 3-3/4" Bore	<b>CYLINDER BLOCK ASSEMBLY</b> complete ..... Consisting of: 1 Cylinder block 1AG-31 Seat and rotator, exh. 2AD-43 Valve stem guides 2AH-9 Retainer locks 1 Inlet valve 1HG-150-A Valve seat insert, inlet 1 Exhaust valve 1 Valve seat insert, exh. 2AF-49D Valve springs 2PC-549 Carburetor studs 1AG-26 Spring seat, inlet	1	21 19 17	(S-10D) (S-12D) (S-14D)
102	AB-114	AB-113	AB-117-A	<b>CYLINDER HEAD</b> ..... AB-117 (S-14D), replaced by AB-117-A.	1	3	8
103	DB-210-2	DB-231	DB-233	<b>PISTON</b> , standard size (cam ground) ..... Pistons are also furnished .010" and .030" oversize.	1	(S-10D) (S-12D) (S-14D)	10 11-3/4 12
104	DR-56	DR-58	DR-61	<b>PISTON RING SET</b> , standard size ..... Consisting of: COMPRESSION RING, top groove ..... SCRAPER RING, 2nd groove ..... OIL RING, 3rd groove ..... EXPANDER for oil ring ..... TRI-CROME RE-RING SET, standard size .....	1		6
105	DC-310	DC-340	DC-353		1		
106	DC-311	DC-339	DC-355		1		
107	DC-324	DC-338	DC-356 DC-357		1		
		DR-59			1		6
				NOTE: All ring sets are available .010", .020" and .030" oversize.			
109	DE-65	DE-79	DE-81	<b>PISTON PIN</b> , standard size ..... Piston pins are also furnished .005" and .010" oversize.	1		3
111	L-86-B-S1 (13027)	L-86-D-S1 (13064)	L-95-S1 (13385)	<b>CARBURETOR</b> , standard (gravity feed) ..... Zenith Model 1408. LQ-45 Repair kit .....	1	1	
	L-86-A-S1 (13022)	L-86-C-S1 (13040)	L-95-A-S1 (13417)	<b>CARBURETOR</b> , for engines with fuel pump ..... LQ-44 Repair kit .....			
				NOTE: The above 'ZENITH' carburetors for Models S12D and S14D can be replaced by 'WALBRO' carburetor (page 32A)- Conversion Kit LTA 100, compl. with air cleaner Refer to stamped part number on carburetor for replacement carburetor or parts. See carburetor bulletins in back of manual for service replacement parts list.			
116	AE-97-D	AE-97-D	AE-102-D	<b>EXHAUST VALVE</b> .....	1		4
117	AE-98	AE-98	AE-103	<b>INLET VALVE</b> .....	1		4
119	AG-26	AG-26		<b>VALVE SPRING SEAT</b> , inlet .....	1		1
120	AG-31	AG-31	AG-31	<b>ROTO-CAP and SEAT</b> , exhaust valve ..... <b>ROTO-CAP and SEAT</b> , inlet and exhaust valve .....	1 2		1 1
140	HG-201-D	HG-201-D	HG-150-D	<b>VALVE SEAT INSERT</b> , exhaust .....	1		1
142	LJ-380 (1" x 2)	LJ-380 (1" x 2)	LJ-280 (1 1/4" x 2 1/4)	<b>PIPE NIPPLE</b> for exhaust muffler .....	1		6
191	Q-38B	Q-38B	Q-38C	<b>ENGINE GASKET SET</b> (replaces Q-38, Q38A) .....	1		8
199	QD-829A	QD-829A	QD-847	<b>GASKET</b> for cylinder head .....	1		1
225	WD-66-A	WD-66-A	WD-66	<b>EXHAUST MUFFLER</b> (order pipe nipple separately) .....	1	1	

**IMPORTANT:** Always give Model, Specification and Serial Numbers as shown on name plate.

**PARTS INTERCHANGEABLE ON MODELS S-10D, S-12D AND S-14D**

REFER TO PAGE 33 FOR NON-INTERCHANGEABLE PARTS.

Ref. No.	Part Number	Description	No.			Net Wt.		
			Req	Lb	Oz	Req	Lb	Oz
115	AD-43	VALVE STEM GUIDE, inlet and exhaust	2		1			
118	AF-49-D	VALVE SPRING, inlet and exhaust ..... AF-60, replaced by AF-49-D.	2		2			
121	AH-9	LOCK for valve spring seat .....	4		1			
123	BA-59-C-S1	CRANKCASE ASSEMBLY (cast iron) .. Consisting of: 1 Crankcase 1 PA-437 Timing pin 4 PC-337 Cylinder studs 1 PF-160 Breaker pin bushing 1 SA-13 Plug for fuel pump hole 1 TC-487 Governor shaft 2 XK-3 Pipe plugs	1		28			
<p><b>NOTE:</b> Beginning with engine serial No. 4080373, BA-59-C crankcase replaces BA-59-A, BA-59A-1 and all subsequent dash numbers. For Service Replacement: Use BA-59-C-S1 crankcase assembly. This crankcase is machined to provide for a fuel pump, optional oil drains and various motor-generator mountings, that previously required separate crankcase part numbers.</p> <p>If a special crankcase was furnished, this would be indicated by a dash (-) number stamped at the location shown in Fig. A. Add this number to the standard crank case part number when ordering. Remachine special cases from available standard BA-59-C-S1 service crankcase, whenever possible.</p>								
 <p align="center">SPECIAL MACHINING DASH NO.</p> <p align="center">STANDARD PART NUMBER</p>			<p align="center">Fig. A      299524C</p>					
124	See Fig. B	GEAR COVER ASSEMBLY ..... Consisting of: 1 BD- Gear cover 1 PH-557A Oil seal 1 ME-212-1 Brg. cup 1 PH-571 Oil seal	1		13			
<p><b>NOTE:</b> The standard gear cover part number for these models of engines is BD-113-C (replaces BD-113). Any special machining is indicated by a dash (-) number stamped behind the basic BD-113-C cast part number, at the location shown in Fig. B. Order by this complete part number and by giving model, specification and serial numbers of engine.</p>								
 <p align="center">PART NUMBER</p>			<p align="center">Fig. B      297762C</p>					
126	BI-374-A	AIR CLEANER BRACKET .....	1		12			
	BI-383-A	Includes RD-142 drip plug For 'ZENITH' carburetor						
127	BK-112-A	FUEL TANK BRACKET, standard .....	1	2	12			
<p><b>NOTE:</b> If bracket is other than standard, order by giving spec and serial numbers — because of various tank mountings with fuel pump and motor-generator.</p>								
128	See Fig. C	CRANKSHAFT ASSEMBLY ..... Consisting of: 1 Crankshaft 1 GA-46 Gear 2 ME-212 Bearings 1 PL-21 Key	1	12	4			
<p><b>NOTE:</b> The standard and basic engine crankshaft part number (raised letters on side of counter-weight), is CA-80. Dash numbers are added to the basic part number to identify special machining at the take-off end. The dash (-) number will be found stamped on the cheek facing the flywheel end of the shaft, as illustrated in Fig. C. Order by complete part number, (dash number added to basic number) and by giving the model, specification and serial numbers of the engine.</p>								
 <p align="center">PART NO.</p>			<p align="center">Fig. C      290652C</p>					
129	DA-74-B-S1	CONNECTING ROD ASSEMBLY for engines beginning with serial No. 4599775 Includes: 1 HG-133A Bushing 2 PD-246 Nuts 2 PE-186 Bolts 1 PG-1143C Dipper DA-74A-S1 for engines previous to serial No. 4599775. Replaced by DA-74B-S1 but if original piston is used, machine inside of piston to 1-3/8" between pin bosses.	1	1	2			
<p><b>NOTE:</b> The connecting rod is furnished LESS the shell bearings. Refer to reference number 136 for part number of the standard size and the undersize shell bearings available.</p>								

**IMPORTANT:** Always give Model, Specification and Serial Numbers as shown on name plate.

**PARTS INTERCHANGEABLE ON MODELS S-10D, S-12D AND S-14D**

REFER TO PAGE 33 FOR NON-INTERCHANGEABLE PARTS.

Ref. No.	Part Number	Description	No.			Ref. No.	Part Number	Description	No.		
			Req.	Lb	Oz				Req.	Lb	Oz
131	EA-134-A	<b>CAMSHAFT and GEAR ASSEMBLY</b> with striker plate and compression release .... PM-232 Torsion Spring for compression release flyweight ..... EA-128A, replaced by EA-134-A. EA-127-A camshaft assembly (less compression release) for engines previous to Serial No. 4225490. For replacement use EA-134-A.	1	2	12	150	ME-216	STEEL BALL for camshaft, 1/2" dia. ..	1		1
			1		1	151	N-105-B	FLYWHEEL ASSEMBLY, includes magnet. For magneto ignition and beginning with engine serial No. 4329320. NC-208D-S1, replaced by N-105-B.  NC-208B-S1, for serial No. 4153189 to 4329319, replaced by N-105-B.  NC-208-S1 for engines to and including serial No. 4153188 - replaced by N-105B-S1 flywheel and sheave assembly.	1		20
132	F-70	VALVE TAPPET with lockscrew .....	2		2					19	8
133	GA-46	CRANKSHAFT GEAR .....	1		5					21	
134	GD-139B-S1	<b>GOVERNOR GEAR and FLYWEIGHT ASSEMBLY</b> ..... Consisting of: 1 GD-139-B Gear 1 PK-118 Snap ring 2 PA-332 Flyweight pins 2 TC-488 Flyweights	1		8	151A	NC-210-6	FLYWHEEL for battery ignition engines with motor-generator.	1		20
							N-105-C	FLYWHEEL with GH-48 ring gear ..... For battery ignition and Bendix starter.			21
							N-105-2	FLYWHEEL with ring gear and rotor for flywheel alternator.			
136	HA-129-S	SHELL BEARING (2 halves) ..... For connecting rod, standard size. NOTE: The following undersize shell bearings are also available. HA-129-S1 ..... (.001" undersize) HA-129-S2 ..... (.002" undersize) HA-129-S10 ..... (.010" undersize) HA-129-S20 ..... (.020" undersize)	1		4		N-105-3	FLYWHEEL with ring gear and rotor for solid state ignition.			
							N-105-4	FLYWHEEL with rotor (less ring gear) for solid state ignition.			
137	HF-52	SPACER for governor control disc .....	1		1	152	PA-425	DOWEL PIN for gear cover .....	2		1
138	HG-133-A	PISTON PIN BUSHING .....	1		1	153	PA-437	POINTER for timing .....	1		1
139	HG-150-A	VALVE SEAT INSERT, inlet .....	1		1	154	PA-438-S1	PUSH PIN for breaker points ..... Includes: PM-223 Spring	1		1
143	LL-168 LL-168-B	BREATHER TUBE, standard ..... For horizontal mounted air cleaner .....	1		2	155	PA-439	FULCRUM PIN for breaker arm ..... (Included in YQ-16 Kit.)	1		1
144	LL-178-12	HOSE for fuel line .....	1		2	156	PB-169-A	ADJUSTING SCREW for valve tappet ....	2		1
145	LO-24	<b>AIR CLEANER - Oil Bath Type</b> .....	1		12	157	PB-186	CONNECTING ROD BOLT .....	2		2
		Service parts:				158	PC-337	STUD for cylinder block .....	4		2
145A		81-179B1 Cap and filter assembly ....	1		1	159	PC-377	STUD for governor control disc .....	1		1
145B		81-176B1K01 Oil cup .....	1		10	160	PC-549	STUD for carburetor mounting .....	2		1
145C		81-615A1 Filter gasket .....	1		1	161	PC-588	STUD for cylinder head and fuel tank bracket .....	3		3
445D		QD-540 Base gasket (Wis. part No.)	1		1	162	PC-593	STUD for oil bath air cleaner, 7-3/8" long	1		2
145E		SD-165 Instruction decal .....	1		1		PC-591	STUD for dry element cleaner, 7-7/16" lg.			2
146	LO-175	<b>AIR CLEANER - Dry Element Type</b> .....	1		1	163	PC-601	STUD for breaker box mounting .....	2		1
		Consisting of:				165	PD-123	NUT for flywheel mounting .....	1		2
146A		LO-175-A Cover .....	1		8	166	PD-147	WING NUT for air cleaner stud .....	1		1
146B		LO-175-B Element .....	1		8	167	PE-66	LOCKWASHER for flywheel mounting ..	1		1
146C		SD-295 Instruction decal .....	1		1	168	PF-160	BREAKER BUSHING .....	1		3
	LO-175-C	<b>AIR CLEANER - horizontal mounted</b> .....	1		4			Ream I. D. to .2785 - .2790 inches after pressing in place.			
		Consisting of:				169	PG-556-2	STRAP for ignition coil .....	1		4
		LO-175-B Element .....	1		8						
		LO-175-D Body .....	1		8						
		SD-295 Decal .....	1		1						
	SA-137	CAP (not illustrated) .....	1		1						
	SA-144	COVER (not illustrated) .....	1		2						
		NOTE: See Page 32A for new air cleaner assembly									
147	ME-212	<b>MAIN BEARING ASSEMBLY</b> .....	2		8						
		Consisting of:									
148		1 ME-212-1 * Bearing cup .....			3						
149		1 ME-212-2 * Bearing cone .....			5						
		* Not sold separately.									

**IMPORTANT:** Always give Model, Specification and Serial Numbers as shown on name plate.

**PARTS INTERCHANGEABLE ON MODELS S-10D, S-12D AND S-14D**

REFER TO PAGE 33 FOR NON-INTERCHANGEABLE PARTS.

Ref. No.	Part Number	Description	No.		Net Wt.		Ref. No.	Part Number	Description	No.		Net Wt.	
			Req	Lb	Oz	Req				Lb	Oz		
170	PG-1196 PG-864	STRAP, for standard, 1.5 gal. tank ..... STRAP, for 2.4 gal. fuel tank .....	2 2		4 6		202	RG-41	SHUT-OFF VALVE and STRAINER .....	1			1
NOTE: Steel Binder Strapping and Seal for mounting fuel tank, on engines sent out from the factory, are not serviceable in the field. Order 2 each of straps, XA-69 screws and PD-239 nuts.													
171	PG-1132	GROUNDING CLIP .....	1		1		203	RJ-165 RJ-171-C (Optional)	DIP STICK (screw in) standard .....	1			2
172	PG-1143-C	OIL DIPPER for DA-74B-S1 conn. rod .. PG-1143-B for engines previous to serial No. 4599775 and DA-74A-S1 conn. rod.	1		3		204	R-123-74	OIL FILLER - DIP STICK Assembly .. Consisting of: L.H. side of gear cover	1			12
173	PH-196 PE-3	WASHER, 1/4" plain steel .....	3		1		204A	LJ-442	1/4" Pipe Nipple, 3-3/8" long	1			5
		WASHER, 1/4" spring lock..... For starter sheave mounting. (Replaces PH-442 rubber faced washer)	3		1		204B	RB-86	Body .....	1			3
174	PH-515	GROMMET for fuel line .....	2		1		204C	RJ-168E-S1	Dip Stick and Cap with QD-715 Gasket .....	1			4
175	PH-557-A	OIL SEAL for crankshaft .....	2		2		205	SA-128-B	BREATHER - INSPECTION COVER .. SA-128-A, replaced by SA-128-B.	1			4
176	PH-571	OIL SEAL for governor lever shaft .....	1		1		206	SA-138	BREAKER BOX (order YD-334 complete box, pin and point assembly.)	1			
178	PI-228 PI-218	ROD, throttle (10-1/16) WALBRO carb. ... ROD, (9-3/8" long) ZENITH carburetor ..	1		1		207	SA-139	BREAKER BOX COVER .....	1			2
179	PI-219 or PI-219-A	ADJUSTING SCREW for governor spring 3-5/8" long, for 2600 to 3600 R.P.M. .... 4-1/4" long, to and including 2500 R.P.M. load.	1		1		209	SD-312	NAME PLATE .....	1			1
180	PK-52	PISTON PIN RETAINING RING .....	2		1			SE-337 SE-337A	FLYWHEEL AIR SHROUD, standard .....	1	2	12	
181	PK-118	SNAP RING for governor gear .....	1		1				For engines with Bendix starter .....	2	8		
182	PK-178	CLIP for throttle rod mounting..... PK-180, PK-177, replaced by PK-178	1		1		211	SE-291	CYLINDER SIDE SHROUD .....	1			6
184	PL-21	WOODRUFF KEY, No. 3 .....	1		1		212	SE-301 SE-301-B	BACK PLATE for flywheel shroud, std. For engine with Bendix starter. ....	1	1	4	
185	PL-48	WOODRUFF KEY, letter E .....	1		1		213	SE-303	SCREEN for rope sheave .....	1			2
187	PM-213	GOVERNOR SPRING .....	1		1		214	SE-309	CYLINDER HEAD COVER .....	1			4
188	PM-216	SPRING for camshaft thrust plunger .....	1		1		216	TC-486	GOVERNOR LEVER .....	1			2
189	PM-223	SPRING for breaker pin .....	1		1		217	TC-487	GOVERNOR SHAFT .....	1			3
192	QC-12-A	GASKET for carburetor flange .....	1		1		218	TC-490	GOVERNOR THRUST SLEEVE .....	1			1
193	QD-816-A	GASKET for stator plate (paper) .....	*		1		219	TC-491-A	CROSS SHAFT and YOKE ASSEMBLY	1			2
		.003"-.004" thick. * Use as required to give .002" to .005" crankshaft end play (2 to 4 used, along with 3 QF-116 shims).											
194	QD-818-B	GASKET for cylinder block .....	1		1		221	U-268 (Obsolete)	STARTING ROPE ASSEMBLY .....	1			6
		QD-818A, replaced by QD-818B.											
195	QD-823	GASKET for breather - insp. cover .....	1		1		222	UC-202 (Obsolete)	STARTING SHEAVE (Sheet metal), Be- ginning with engine serial No. 5368079. (Sheave is furnished less screen) UC-189B (aluminum) serial No. 4153188 to serial No. 5368078, not available. Use UC-202 and enlarge hole in fly- wheel shroud to 7-1/4" dia.  UC-189 for engines to serial No. 4153187. For replacement use UC-202 with 3 HF-631 spacers, and enlarge shroud hole to 7-1/4".				
196	QD-838	GASKET for breaker box cover .....	1		1		NOTE: Rewind (recoil) starter is now standard equipment. See section following parts list.						
197	QD-824	GASKET for gear cover .....	1		1		223	VC-43-A	DISC ASSEMBLY for gov. control rod ..	1			3
198	QD-828	GASKET, air cleaner brkt. ZENITH carb.	1		1		226	WE-415-S1	FUEL TANK (1.5 gal. capacity) std. with RC-122 filler cap. WE-402 tank with RC-87 cap, replaced by WE-415-S1.	1	2		6
200	QF-116-A	SHIM for stator plate, .010" thick steel QF-116, replaced by QF-116-A.	3		1			WE-417-S1	2.4 gal. tank with RC-122 cap (requires special bracket) .....				3
201	RF-1439	ELBOW in carburetor, for fuel line .....	1		1		WE-344 with RC-77 cap, replaced by WE-417-S1.						

**IMPORTANT: Always give Model, Specification and Serial Numbers as shown on name plate.**

**PARTS INTERCHANGEABLE ON MODELS S-10D, S-12D AND S-14D**

REFER TO PAGE 33 FOR NON-INTERCHANGEABLE PARTS.

Ref. No.	Part Number	Description	No.		Net Wt.		Ref. No.	Part Number	Description	No.		Net Wt.	
			Req		Lb	Oz				Req		Lb	Oz
		<b>NOTE:</b> Fuel tanks are mounted to the tank bracket with steel binder strapping, which is not serviceable in the field. When replacing fuel tank, order service replacement straps (Ref. 170).							<b>FUEL PUMP MOUNTING</b> (Not part of standard engine)				
227	RC-122 RC-123-A	CAP (screw type) for WE-415 tank ..... CAP with gauge, available for WE-415 fuel tank ..... RC-87 cap for obsolete WE-402 bayonet neck type fuel tank .....	1		2		245	LL-178-6	FUEL LINE, pump to carburetor .....	1		1	
					4		246	LP-62F-S1	FUEL PUMP for engines beginning with serial No. 5307640 .....	1		10	
					2				LQ-51 Repair Kit for LP-62F-S1 .....	1		4	
228	XD-31	SCREW (Special hardness) 3/8"-16 thread x 1-3/4" long ..... For mounting cylinder head.	5		2				LP-42M-S1, replaced by LP-62F-S1. LQ-28 Repair Kit for LP-42M-S1 pump ..	1		4	
229	XK-3	PIPE PLUG, 3/8" square head ..... For oil drain.	2		2		247	QD-670	FLANGE GASKET .....	1		1	
230	Y-132-S1	STATOR PLATE ASSEMBLY, mag. ign. Includes: 1 ME-212-1 Bearing cup 1 PH-557-A Oil seal 1 YL339B20 Lead wire 1 YM23 Coil assembly 1 YM24 Coil clip	1	1	8		248	RF-1439	ELBOW in pump outlet and inlet .....	2		1	
230A	BG-350A-S1	BEARING PLATE ASSEMBLY, fan end For battery ignition, flywheel alternator or solid state ignition engines. Includes: 1 ME-212-1 Bearing cup 1 PH-557-A Oil seal Y-132A-S1, replaced by BG-350A-S1	1	1	4			<b>STANDARD HARDWARE</b>					
231	YD-6-51 (Optional) YD-6-52	SPARK PLUG, 18mm, Champion #D-16J SPARK PLUG, AC #86 Commercial .....	1		3		250	PD-9	NUT, 1/4"-28 thread, hexagon steel .... 1-for governor control lever. 1-for governor control disc.	2		1	
232	YD-316	INSULATING WASHER (outer) for ground stud .....	1		1		251	PD-10	NUT, 5/16"-24 thread, hexagon steel .. For carburetor mounting.	2		1	
233	YD-20-A	RUBBER NIPPLE for coil terminal .....	1		1		252	PD-12	NUT, 7/16"-20 thread, hexagon steel .. For cylinder block mounting.	4		1	
234	YD-321	TERMINAL STUD for ground clip .....	1		1		254	PD-239	NUT, 1/4"-20 thread, square steel .....	2		1	
235	YD-324	INSULATING WASHER (inner) for ground stud .....	1		1				For fuel tank straps.				
236	YD-326	TERMINAL STRIP for breaker arm .....	1		1		255	PD-77-1	NUT, 1/4"-20 thread, hexagon jam .....	1		1	
237	YD-334-51	BREAKER BOX and PIN ASSEMBLY .... Complete - with points and condenser.	1		8		256	PD-79	NUT, 3/8"-16 thread, hexagon steel .... For fuel tank bracket studs.	3		1	
238	YD-339	CONDENSER CLAMP .....	1		1		257	PD-153-2	NUT, No. 8-32, hexagon steel .....	2		1	
239	YF-5-B YF-37	COIL (12 volt) for battery ignition .....	1	1	6		258	PD-155	NUT, No. 5-40 thread, hexagon steel .... For governor control rod lock.	1		1	
240	YL-339B-20	HIGH TENSION LEAD for magneto coil	1		3		259	PD-246	NUT (special) 5/16"-24 thread .....	2		1	
240A	YL-339-20	HIGH TENSION LEAD for battery ign. ...			3				For connecting rod bolts.				
	YL-339-6	LEAD for solid state ignition .....			2		260	PE-3	LOCKWASHER, 1/4" spring lock .....	11		1	
241	YL-352-19	IGNITION WIRE, breaker box to battery ignition coil .....	1		1				1-for governor lever. 2-for governor control disc. 2-for fuel tank straps. 2-for fuel pump mounting. 4-for air shroud to back plate.				
242	YQ-16	POINTS and CONDENSER KIT .....	1		4		261	PE-4	LOCKWASHER, 5/16" spring lock .....	13		1	
		Consisting of: 1 YD-315-A Condenser 1 YD-326 Terminal strip 1 YD-339 Condenser clip 1 YD-340 Breaker assembly Includes: 1 PA-439 Fulcrum pin 1 XA-121 Breaker arm screw					262	PE-5	LOCKWASHER, 3/8" spring lock .....	5		1	
									3-for mounting fuel tank bracket. 1-for cylinder block capscREW. 1-for battery ignition coil strap.				
							263	PE-6	LOCKWASHER, 7/16" spring lock .....	4		1	
									For cylinder block mounting.				
							264	PE-45	LOCKWASHER, No. 10 external tooth .. For air cleaner bracket mt'g. (Replaces PH-312 plain washer).	3		1	
							265	PE-72	LOCKWASHER, No. 8 internal .....	1		1	
									For ground clip.				


**IMPORTANT:** Always give Model, Specification and Serial Numbers as shown on name plate.

## PARTS INTERCHANGEABLE ON MODELS S-10D, S-12D AND S-14D

REFER TO PAGE 33 FOR NON-INTERCHANGEABLE PARTS.

Ref. No.	Part Number	Description	No.			Net Wt.		
			Req	Lb	Oz	Req	Lb	Oz
266	PE-89	LOCKWASHER, No. 8 Positive ..... 1-for ground terminal. 1-for breaker point bracket.	2		1			
267	PF-18	PLUG, 1/8" pipe, slotted, steel ..... For air cleaner bracket.	1		1			
269	PH-14-D	WASHER, 5/16" I.D. x 19/32" O.D. x 1/16" thick, steel ..... 2-for carburetor mounting. 4-for coil-stator plate mounting.	6		1			
270	PH-86-B	PLAIN WASHER, 11/64" I.D. x 3/8" O.D. .... For ground terminal stud.	1		1			
271	PH-209-B	PLAIN WASHER, 5/16" steel ..... For governor lever mounting.	1		1			
272	PH-583	PLAIN WASHER, 11/64" I.D. x 13/32" O.D. .... For breaker point bracket. (Replaces PH-236)	1		1			
273	PH-312	PLAIN WASHER, 3/16" steel ..... For breaker box stud.	2		1			
274	PH-513	WASHER, 13/32" I.D. x 13/16" O.D. x 1/8" thick, steel, hardened ..... For cylinder head mounting.	9		1			
276	XA-67	SCREW, No. 4 x 1/4" long, self-tapping, sheet metal ..... For name plate to shroud.	4		1			
277	XA-69	SCREW, 1/4"-20 x 2" long round head .. For fuel tank straps.	2		1			
278	XA-126	SCREW, No. 6-32 thread x 1/2" long, steel finished pan head ..... For breaker point bracket. XA-118, 5/16" long, repl'd. by XA-126.	1		1			
279	XA-119	SCREW, No. 8 x 1/4" long, round head, self tapping ..... For condenser mounting.	1		1			
280	XA-121	SCREW, No. 6-20 x 3/8" long, round head, self tapping ..... For breaker arm terminal. (In YQ-16 Kit)	1		1			
281	XD-6	SCREW, 1/4"-20 x 3/4" long, hex. head ..... For fuel pump mounting.	2		1			
282	XD-6	SCREW, 1/4"-20 x 3/4" long, hex. head ..... For UC-202 sheetmetal starting sheave.	3		1			
	XD-9	(1-1/2" long) for obsolete UC-189B ..... Aluminum starting sheave.	3		1			
	XD-10	(1-3/4" long) for obsolete UC-189 sheave	3		1			
283	XD-17	SCREW, 5/16"-18 x 1" long, hex. head .. For coil-stator plate mounting.	4		1			
285	XD-22	SCREW, 5/16"-18 thread x 1-3/4" long, hexagon head ..... For gear cover mounting.	9		2			
286	XD-28	SCREW, 3/8"-16 thread x 1-1/8" long, hexagon head ..... For cylinder block in valve chamber.	1		1			
287	XD-25	SCREW, 3/8"-16 x 3/4" long, hex. head ..... For mounting ignition coil.	1		1			
289	XD-157	SCREW, 1/4"-20 thread x 1/2" long, hexagon head, with external lockwasher ..... 2-for air shroud to cylinder head. 2-for breather inspection cover. 3-for back plate to crankcase. 4-for cylinder side cover.	11		1			
	XD-4	SCREWless lockwasher ..... For air shroud to back plate.	4		1			
290	XD-166	SCREW, No. 10-32 thread x 3/4" long, indented hexagon head ..... For air cleaner bracket to carburetor.	3		1			

### YC-66-D-S1 HIGH TEMPERATURE SAFETY SWITCH KIT



Ref. No.	Part Number	Description	No.			Net Wt.		
			Req	Lb	Oz	Req	Lb	Oz
	YC-66-D-S1	HIGH TEMPERATURE SAFETY SWITCH KIT - Complete ..... Consisting of:						8
295	PH-22	WASHER, 3/8" I.D., plain steel ..... For switch to cylinder head mounting.	1		1			
296	SD-233	INSTRUCTION DECAL .....	1		1			
297	XD-32	CAPSCREW, 3/8"-16 thread x 2" long, hexagon head ..... For switch to cylinder head mounting.	1		1			
298	YC-66-D	HIGH TEMPERATURE SAFETY SWITCH ..... For replacement, order YC-66-D-S1 Kit.	1		3			
299	YL-357-42	WIRE ASSEMBLY, 42" long, with terminals. (Wire coiled to suit all models.)						
	PG-57	CLIP for supporting wire to cylinder side shroud ..... Not illustrated nor included in Kit.	1		1			


**IMPORTANT:** Always give Model, Specification and Serial Numbers as shown on name plate.

# VARIABLE SPEED GOVERNOR CONTROL ASSEMBLIES


For Models S10D, S12D, S14D

TT-96

TT-96-A



299525C



297761C

Ref. No.	Part Number	Description	No. Req.	Net Wt.	
				Lb	Oz
	TT-96	INCLUDES THE NEXT THREE ITEMS:			
300	PD-251	LOCK NUT for handle, 1/4"-28 thread .. PD-217, replaced by PD-251.	1	1	
301	PH-282	SPRING WASHER for handle .....	1	1	
302	VB-244	CONTROL HANDLE .....	1	1	
		THE FOLLOWING ITEMS ARE PART OF THE STANDARD ENGINE AND ARE NOT INCLUDED AS PART OF TT-96 ASSEMBLY.			
303	HF-52	SPACER for control disc .....	1	1	
304	PC-377	STUD for control disc .....	1	1	
305	PI-219	ADJUSTING SCREW, 3-5/8" long .....	1	1	
	PI-219-A	4-1/4" long - below 2600 R.P.M. ....	1	1	
306	VC-43-A	CONTROL DISC ASSEMBLY .....	1	3	

Ref. No.	Part Number	Description	No. Req.	Net Wt.	
				Lb	Oz
	TT-96-A	INCLUDES THE NEXT FOUR ITEMS:			
310	PD-187	LOCK NUT for spiral wire casing .....	2	1	
311	PD-251	LOCK NUT for control disc, 1/4"-28 thd. PD-217, replaced by PD-251.	1	1	
312	PG-1104	BRACKET for casing support .....	1	5	
313	PH-30-A	WASHER for control disc .....	1	1	
314	---	CONTROL ASSEMBLY with wire and casing: Order by giving engine spec number, and required length. NOT INCLUDED AS PART OF TT-96-A ASSEMBLY.			
		THE FOLLOWING ITEMS ARE PART OF THE STANDARD ENGINE AND ARE NOT INCLUDED AS PART OF TT-96-A ASSEMBLY.			
315	HF-52	SPACER for control disc .....	1	1	
316	PC-377	STUD for control disc .....	1	1	
317	PI-219	ADJUSTING SCREW, 3-5/8" long .....	1	1	
	PI-219-A	4-1/4" long - below 2600 R.P.M. ....	1	1	
318	VC-43-A	CONTROL DISC ASSEMBLY .....	1	3	


**IMPORTANT:** Always give Model, Specification and Serial Numbers as shown on name plate.

# WW-102 CLUTCH AND POWER TAKE-OFF ASSEMBLY

## FOR ENGINE MODELS

beginning with Serial Number 4306847.

WW-102-D (obsolete); used on engines previous to Serial No. 4306847. Had a 1-1/4" dia. take-off shaft, whereas WW-102 has a 1-3/16" dia. shaft. The non-interchangeable clutch housing, oil seal and take-off shaft for WW-102-D are specified in Parts List; all other components are interchangeable.



**NOTE:** Engines equipped with a Clutch and Power Take-off Assembly require a special Gear Cover and Crankshaft as follows:

141165C

### BD-113C-2-S2 GEAR COVER ASSEMBLY (Not illustrated)

Includes:

1 ME-212-1 Bearing cup

1 PH-557-A Crankshaft oil seal (Mount with lips outward)

1 PH-571 Governor lever shaft seal

### CA-80-1-S1 CRANKSHAFT ASSEMBLY (Not illustrated)

Includes:

1 GA-46 Gear

2 ME-212-1 Bearing cups

1 PL-21 Key

1 HG-182 Bushing

2 ME-212-2 Bearing cones

Ref. No.	Part Number	Description	No.	Net Wt.	
			Req	Lb	Oz
	WW-102	CLUTCH and POWER TAKE-OFF ASSEMBLY .....	1	28	
		Consisting of:			
300	BG-156	PLATE for bearing retainer .....	1	8	
301	BG-230-2	CLUTCH HOUSING for WW-102 .....	1	6	
	BG-230-3	for obsolete WW-102-D .....		6	
302	BH-115-A	COVER for inspection hole .....	1	2	
303	HG-182	PILOT BUSHING for crankshaft .....	1	1	
304	LO-44	BREATHER ASSEMBLY .....	1	1	

Ref. No.	Part Number	Description	No.	Net Wt.	
			Req	Lb	Oz
305	ME-79-A	BEARING for take-off shaft .....	1	10	
306	PC-392	STUD for mounting clutch housing .....	4	2	
307	PH-234-A	OIL SEAL for shifter lever shaft .....	1	2	
308	PH-280	OIL SEAL, take-off shaft, for WW-102 ..	1	3	
	PH-529	for obsolete WW-102-D .....		3	
309	PK-97	RETAINING RING for bearing .....	2	1	
310	QD-551	GASKET for inspection hole cover .....	1	1	
311	QD-650-1	GASKET for housing mounting .....	1	1	

**IMPORTANT:** Always give Model, Specification and Serial Numbers as shown on name plate.



## WW-102 CLUTCH AND POWER TAKE-OFF ASSEMBLY





Ref. No.	Part Number	Description	No. Req	Net Wt.	
				Lb	Oz
312	SD-79	TAG for oil instructions .....	1		1
313	SD-125-A	INSTRUCTION PLATE .....	1		1
		For clutch adjustment.			
314	VB-55-1	SHIFTER LEVER .....	1	2	
315	VB-64-A	SHIFTER YOKE .....	1	1	4
316	WA-61	SHAFT for shifter yoke .....	1	1	
317	WA-101	TAKE-OFF SHAFT for WW-102 .....	1	2	6
		WA-131 for obsolete WW-102-D .....		3	
318	WC-280-B	CLUTCH, Rockford Model 4-1/2 LOC No. CLA-1761 .....	1	1	8
		NOTE: See Rockford illustration and parts list for clutch parts. Page 46.			
319	XD-14-2	SET SCREW for clutch drive hub .....	1		1
		<b>STANDARD HARDWARE</b>			
322	PD-12	NUT, 7/16"-20 thread, hexagon steel .. For clutch housing studs.	4		1
323	PE-6	LOCKWASHER, 7/16" Positive .....	4		1
		For clutch housing stud nuts.			
324	PE-46	LOCKWASHER, 5/16" External Everlock For drive hub set screw.	1		1
325	PH-30	WASHER, 1/4" I.D. x 7/16" O.D. x 1/16" thick, plain copper .....	4		1
		For bearing retainer plate.			
	PH-30-A	WASHER, steel, for inspection cover ...	4		1
326	PL-86	KEY, 1/4" square x 1" long .....	1		1
		For clutch drive hub.			
327	SA-58	PLUG, 1-3/8" expansion .....	1		1
		For shifter shaft hole.			
329	XA-34	SCREW, 1/4"-20 thread x 1/2" long, indented hexagon head .....	4		1
		For inspection hole cover.			
330	XD-8	SCREW, 1/4"-20 thread x 1-1/4" long, hexagon head .....	4		1
		For bearing retainer plate.			
331	XD-30	SCREW, 3/8"-16 thread x 1-1/2" long, hexagon head .....	1		1
		For shifter lever.			
332	PA-341	ROLL PIN, 1/4" dia. x 1-1/8" long ...	2		1
		For shifter yoke to shaft.			
333	XK-1	PIPE PLUG, 1/8" square head .....	2		1
		For oil level.			
334	XK-2	PIPE PLUG, 1/4" square head .....	1		1
		For oil drain.			
	XK-3	PIPE PLUG, 3/8" square head .....	1		1
		For clutch adjustment (not illustrated).			
335	XK-77-A	STREET ELL, 1/8" x 45°, brass .....	1		1
		For breather mounting.			

**IMPORTANT:** Always give Model, Specification and Serial Numbers as shown on name plate.



# WW-79-A Etc. CLUTCH REDUCTION GEAR ASSEMBLIES

Beginning with Serial Number 4306847 — see note on following page.

Position of Take-Off Shaft is Determined When Viewed From Cranking End of Engine	Assembly Part Number	Reduction Ratio	Rotation of Take-off Shaft	Driver Gear Part No.	Ref. No. 501 Driven Gear Part No.	Ref. No. 502 Chain Part No.	Ref. No. 503 Housing Part No.	Ref. No. 504 Clutch Shaft Part No.
<b>TAKE-OFF SHAFT BELOW</b> 	WW-79-A	2.12 to 1	Engine-Wise	GG-138	GG-137	GJ-19	BG-232	WA-95
	WW-79A-1	3.08 to 1	Engine-Wise	GG-133	GG-132	GJ-20	BG-232	WA-95
	WW-79A-2	4.00 to 1	Engine-Wise	GG-123	GG-132	GJ-19	BG-232	WA-95
	WW-79A-3	2.03 to 1	Counter Engine-Wise	GG-139	GG-119-2	.....	BG-232	WA-95
	WW-79A-4	2.96 to 1	Counter Engine-Wise	GG-140	GG-136	.....	BG-232	WA-95
	WW-79A-5	4.06 to 1	Counter Engine-Wise	GG-141	GG-135	.....	BG-232	WA-95
	WW-79A-6	5.06 to 1	Counter Engine-Wise	GG-142	GG-134-1	.....	BG-232	WA-95
WW-79A-7	6.00 to 1	Counter Engine-Wise	On Shaft	GG-134	.....	BG-232	WA-95-A	
<b>TAKE-OFF SHAFT ON LEFT HAND SIDE</b> as viewed from cranking end 	WW-79A-8	2.12 to 1	Engine-Wise	GG-138	GG-137	GJ-19	BG-232-1	WA-95
	WW-79A-9	3.08 to 1	Engine-Wise	GG-133	GG-132	GJ-20	BG-232-1	WA-95
	WW-79A-10	4.00 to 1	Engine-Wise	GG-123	GG-132	GJ-19	BG-232-1	WA-95
	WW-79A-11	2.03 to 1	Counter Engine-Wise	GG-139	GG-119-2	.....	BG-232-1	WA-95
	WW-79A-12	2.96 to 1	Counter Engine-Wise	GG-140	GG-136	.....	BG-232-1	WA-95
	WW-79A-13	4.06 to 1	Counter Engine-Wise	GG-141	GG-135	.....	BG-232-1	WA-95
	WW-79A-14	5.06 to 1	Counter Engine-Wise	GG-142	GG-134-1	.....	BG-232-1	WA-95
WW-79A-15	6.00 to 1	Counter Engine-Wise	On Shaft	GG-134	.....	BG-232-1	WA-95-A	
<b>TAKE-OFF SHAFT ON RIGHT HAND SIDE</b> as viewed from cranking end 	WW-79A-16	2.12 to 1	Engine-Wise	GG-138	GG-137	GJ-19	BG-232-2	WA-95
	WW-79A-17	3.08 to 1	Engine-Wise	GG-133	GG-132	GJ-20	BG-232-2	WA-95
	WW-79A-18	4.00 to 1	Engine-Wise	GG-123	GG-132	GJ-19	BG-232-2	WA-95
	WW-79A-19	2.03 to 1	Counter Engine-Wise	GG-139	GG-119-2	.....	BG-232-2	WA-95
	WW-79A-20	2.96 to 1	Counter Engine-Wise	GG-140	GG-136	.....	BG-232-2	WA-95
	WW-79A-21	4.06 to 1	Counter Engine-Wise	GG-141	GG-135	.....	BG-232-2	WA-95
	WW-79A-22	5.06 to 1	Counter Engine-Wise	GG-142	GG-134-1	.....	BG-232-2	WA-95
WW-79A-23	6.00 to 1	Counter Engine-Wise	On Shaft	GG-134	.....	BG-232-2	WA-95-A	
<b>TAKE-OFF SHAFT ON TOP</b> 	WW-79A-24	2.12 to 1	Engine-Wise	GG-138	GG-137	GJ-19	BG-232-3	WA-95
	WW-79A-25	3.08 to 1	Engine-Wise	GG-133	GG-132	GJ-20	BG-232-3	WA-95
	WW-79A-26	4.00 to 1	Engine-Wise	GG-123	GG-132	GJ-19	BG-232-3	WA-95
	WW-79A-27	2.03 to 1	Counter Engine-Wise	GG-139	GG-119-2	.....	BG-232-3	WA-95
	WW-79A-28	2.96 to 1	Counter Engine-Wise	GG-140	GG-136	.....	BG-232-3	WA-95
	WW-79A-29	4.06 to 1	Counter Engine-Wise	GG-141	GG-135	.....	BG-232-3	WA-95
	WW-79A-30	5.06 to 1	Counter Engine-Wise	GG-142	GG-134-1	.....	BG-232-3	WA-95
WW-79A-31	6.00 to 1	Counter Engine-Wise	On Shaft	GG-134	.....	BG-232-3	WA-95-A	

See following page for weights and description

# WW-79-A Etc. CLUTCH REDUCTION GEAR ASSEMBLIES

beginning with Serial No. 4306847 – see note below.

## WEIGHTS OF PARTS SHOWN ON PRECEDING PAGE

PART NUMBER	NET WT.		PART NUMBER	NET WT.		PART NUMBER	NET WT.	
	LBS	OZ		LBS	OZ		LBS	OZ
BG-232 .....	20		GJ-19 (23" long) .....	1	9	WW-79A-14 .....	54	8
BG-232-1 .....	20		GJ-20 (23½" long) .....	1	10	WW-79A-15 .....	54	8
BG-232-2 .....	20		WA-95 .....	1	3	WW-79A-16 .....	53	8
BG-232-3 .....	20		WA-95-A .....	1	8	WW-79A-17 .....	53	8
GG-119-2 (61 teeth) .....	4	14	WW-79-A .....	53	8	WW-79A-18 .....	53	
GG-123 (10 teeth) .....		5	WW-79A-1 .....	53	8	WW-79A-19 .....	54	
GG-132 (40 teeth) .....	3	13	WW-79A-2 .....	53		WW-79A-20 .....	55	
GG-133 (13 teeth) .....		11	WW-79A-3 .....	54		WW-79A-21 .....	54	8
GG-134 (78 teeth) .....	7	1	WW-79A-4 .....	55		WW-79A-22 .....	54	8
GG-134-1 (76 teeth) .....	6	12	WW-79A-5 .....	54	8	WW-79A-23 .....	54	8
GG-135 (73 teeth) .....	6	8	WW-79A-6 .....	54	8	WW-79A-24 .....	53	8
GG-136 (68 teeth) .....	6	4	WW-79A-7 .....	54	8	WW-79A-25 .....	53	8
GG-137 (36 teeth) .....	3	8	WW-79A-8 .....	53	8	WW-79A-26 .....	53	
GG-138 (17 teeth) .....	1	5	WW-79A-9 .....	53	8	WW-79A-27 .....	54	
GG-139 (30 teeth) .....	1	15	WW-79A-10 .....	53		WW-79A-28 .....	55	
GG-140 (23 teeth) .....	1	8	WW-79A-11 .....	54		WW-79A-29 .....	54	8
GG-141 (18 teeth) .....		12	WW-79A-12 .....	55		WW-79A-30 .....	54	8
GG-142 (15 teeth) .....		5	WW-79A-13 .....	54	8	WW-79A-31 .....	54	8

## INTERCHANGEABLE PARTS OF WW-79-A Etc. CLUTCH REDUCTION GEAR ASSEMBLIES

**NOTE:** WW-79-C etc. (obsolete); used on engines previous to Serial No. 4306847. Had a 1-1/4" dia. take-off shaft, whereas WW-79-A etc. has a 1-1/8" dia. shaft. The non-interchangeable oil seal and take-off shaft are specified in Parts List; all other components are interchangeable.

Engines equipped with a Clutch Reduction Gear Assembly require special Gear Cover and Crankshaft Assemblies as follows:

### BD-113C-2-S2 GEAR COVER ASSEMBLY (Not illustrated)

Includes:

- |                        |  |
|------------------------|--|
| 1 ME-212-1 Bearing cup | 1 PH-557-A Crankshaft oil seal (Mount with lips outward) |
|                        | 1 PH-571 Governor lever shaft seal                       |

### CA-80-1-S1 CRANKSHAFT ASSEMBLY (Not illustrated)

Crankshaft assemblies include the following:

- |                  |                          |             |
|------------------|--------------------------|-------------|
| 1 GA-46 Gear     | 2 ME-212-1 Bearing cups  | 1 PL-21 Key |
| 1 HG-182 Bushing | 2 ME-212-2 Bearing cones |             |

Ref. No.	Part Number	Description	No. Req.	Net Wt.	
				Lb	Oz
505	BG-233	PLATE for bearing retainer .....	1		4
506	BH-115-A	COVER for inspection hole .....	1		2
507	BH-157	COVER for housing .....	1	9	
508	HF-230	SPACER for clutch shaft bearing .....	1		1
509	HG-182	BUSHING for clutch shaft pilot .....	1		1
510	LO-44	BREATHER .....	1		1
511	ME-10	BEARING for clutch shaft .....	1		6
512	ME-92	NEEDLE BEARING inner .....	1		3

Ref. No.	Part Number	Description	No. Req.	Net Wt.	
				Lb	Oz
513	ME-93	NEEDLE BEARING outer .....	1		4
514	PC-392	STUD for housing to crankcase mounting	4		2
515	PH-234-A	OIL SEAL for shifter lever shaft .....	1		2
516	PH-265	OIL SEAL, take-off shaft for WW-79-A etc. PH-529 for obsolete WW-79-C etc. ....	1		3 3
517	PK-76	RETAINING RING for clutch shaft mtg.	1		1
518	QD-650-1	GASKET for housing to crankcase mounting .....	1		1
519	QD-551	GASKET for inspection hole cover .....	1		1

**IMPORTANT:** Always give Model, Specification and Serial Numbers as shown on name plate.


# INTERCHANGEABLE PARTS OF WW-79-A Etc. CLUTCH REDUCTION GEAR ASSEMBLIES

Ref. No.	Part Number	Description	No. Req	Net Wt.	
				Lb	Oz
520	QD-651	GASKET for cover to housing .....	1		1
521	SD-79	TAG for oil instruction .....	1		1
522	SD-125-A	INSTRUCTION PLATE .....	1		1
		For clutch adjustment.			
523	VB-55-1	SHIFTER LEVER .....	1	2	
524	VB-64-A	SHIFTER YOKE .....	1	1	4
525	WA-61	SHIFTER SHAFT .....	1	1	
526	WA-69	TAKE-OFF SHAFT for WW-79-A etc. ....	1	2	2
		WA-130 for obsolete WW-79-C etc. ....		3	
527	WC-280-B	CLUTCH, Rockford Model 4½ LOC, No. CLA-1761 .....	1	8	6
		NOTE: See Rockford illustration and parts list for clutch parts. Page 46.			
528	XD-14-2	SET SCREW for clutch drive hub .....	1		1
<b>STANDARD HARDWARE</b>					
529	PA-289	TAPER PIN, 3/16" dia. x 5/8" long, half taper .....	2		1
		For cover to housing mounting.			
530	PD-12	NUT, 7/16"-20 thread, hexagon .....	4		1
		For housing to crankcase studs.			
531	PE-4	LOCKWASHER, 5/16" Positive .....	7		1
		For cover to housing — above oil level.			
532	PE-6	LOCKWASHER, 7/16" Positive .....	4		1
		For housing to crankcase studs.			
533	PE-46	LOCKWASHER, 5/16" external Everlock .....	1		1
		For drive hub set screw.			
534	PH-14	WASHER, 5/16" I.D. x 19/32" O.D. x 1/16" thick, plain copper .....	3		1
		For cover to housing — below oil level.			
535	PH-30	WASHER, 1/4" I.D. x 7/16" O.D. x 1/16" thick, plain copper .....	7		1
		4-for inspection hole cover.			
		3-for bearing retainer plate.			
536	PL-16	KEY, No. 11 Woodruff .....	1		1
		For driver gear mounting.			
537	PL-50	KEY, No. 16 Woodruff .....	1		1
		For driven gear mounting.			
538	PL-86	KEY, 1/4" square x 1" long .....	1		1
		For drive hub mounting.			
539	SA-58	PLUG, 1-3/8" expansion .....	1		1
		For shifter shaft hole.			
540	XA-34	SCREW, 1/4"-20 thread x 1/2" long, indented hexagon head .....	4		1
		For inspection hole cover.			

Ref. No.	Part Number	Description	No. Req	Net Wt.	
				Lb	Oz
542	XD-7	SCREW, 1/4"-20 thread x 1" long, hexagon head .....	3		1
		For bearing retainer plate.			
543	XD-17	SCREW, 5/16"-18 thread x 1" long, hexagon head .....	10		1
		For cover to housing mounting.			
544	XD-30	SCREW, 3/8"-16 thread x 1-1/2" long, hexagon head .....	1		1
		For clamping shifter lever.			
545	PA-341	ROLL PIN, 1/4" dia. x 1-1/8" long ....	2		1
		For shifter yoke to shaft.			
546	XK-1	PLUG, 1/8" square head, pipe .....	3		1
		For oil level holes.			
547	XK-3	PLUG, 3/8" square head, pipe .....	3		1
		For oil drain holes.			

**IMPORTANT:** Always give Model, Specification and Serial Numbers as shown on name plate.

**WC-280B CLUTCH ASSEMBLY**  
Rockford No. CLA-1761



206584C-A

Ref. No.	Part Number	Description	No. Req.
1	63-CL-7248-1	CLUTCH HOUSING .....	1
2	63-CL-7012	ADJUSTMENT LOCK .....	1
3	63-CL-8807-1	SCREW for adjustment lock, 1/4"-20 thread x 3/8" long, hexagon head .....	1
4	63-CL-3468	WASHER for adjustment lock, 1/4" Shakeproof .....	1
5	63-UCL-5230	DRIVE MEMBER ASSEMBLY .....	1
	*	Consisting of:	
		Splined center and plate assembly .....	1
6	63-CL-4096-18	Facing (Raybestos No. 500B) .....	2
7	63-CL-1011	Brass rivet .....	6
8	63-UCL-1-5228-A	PRESSURE PLATE and LEVER ASSEMBLY .....	1
		Consisting of:	
	63-UCL-5228	Pressure plate assembly .....	1
10	63-CL-5543	Lever .....	6
11	63-CL-5156	Lever pin .....	3
12	63-LM-408	Roller .....	3
		63-CL-4775 Roller and 63-CL-4971 Pin replaced by 63-LM-408.	
13	63-CL-5092	Cotter pin, 1/16" x 3/8" long .....	3
14	63-CL-4776	CONNECTING LINK .....	6
15	63-CL-5153	LINK PIN (long) .....	3
16	63-CL-5152	LINK PIN (short) .....	3
17	63-CL-5092	COTTER PIN for link pins, 1/16" x 3/8" .....	6


Ref. No.	Part Number	Description	No. Req.
18	63-UCL-7-5229	RELEASE SLEEVE ASSEMBLY .....	1
		Consisting of:	
19	63-CL-5229	Release sleeve .....	1
20	63-UCL-14-4966	Release bearing assembly .....	1
		Consisting of:	
		Release bearing (2 halves)	
21	63-CL-3335-1	Hex. hd. screw, 5/16"-24 thread x 1-3/4" long .....	2
22	63-CL-7356	Elastic stopnut, 5/16"-24 thread .....	2
23	63-CL-4964	ADJUSTING RING .....	1
24	63-CL-5087	SPRING .....	3
25	63-CL-5318	CLAMP SCREW, 3/8"-24 thread x 2-1/2" long, hexagon head .....	2
26	63-CL-5319	NUT, 3/8"-24 thread, light hexagon .....	2
27	63-CL-5211	SCREW LOCK .....	2
28	63-PT-353	LOCKWASHER, 3/8" Positive .....	2
		(* ) Not serviced separately from sub-assembly it is included in.	

**IMPORTANT:** Always give Model, Specification and Serial Numbers as shown on name plate.



# WW-64-P, WW-64-P-1, WW-64-P-2, WW-64-P-6 REDUCTION GEAR ASSEMBLIES

FOR ENGINE MODELS S-10D AND S-12D, beginning with Serial Number 4265613. WW-64-N, WW-64N-1, WW-64N-2, WW-64N-6 (obsolete), used on engines previous to Serial No. 4265613. Had a 1-1/4" dia. take-off shaft, whereas WW-64-P etc. has a 1-1/8" dia. shaft. The non-interchangeable oil seal and shaft for WW-64-N etc. are specified in Parts List; all other components are interchangeable.



NOTE: The reduction gear assembly part number is stamped on the oil instruction tag.

299526C

ASSEMBLY PART NUMBER	REDUCTION RATIO	ROTATION AT TAKE-OFF SHAFT	NET WEIGHT	
			LBS	OZ
WW-64-P	4 to 1	Counter-Enginewise	23	
WW-64-P-1	2:076 to 1	Counter-Enginewise	23	
WW-64-P-2	3.4 to 1	Engine-Wise (chain drive)	22	
WW-64-P-6	6 to 1	Counter-Enginewise	23	

NOTE: Engines equipped with a reduction unit, require a special gear cover and crankshaft as follows: (Not illustrated)

**BD-113C-3-S2 GEAR COVER ASSEMBLY** (For all reduction units)

**CA-80-2-S1 CRANKSHAFT ASSEMBLY**  
For WW-64-P, WW-64-P-1, WW-64-P-2

**CA-80-112-S1 CRANKSHAFT ASSEMBLY**  
For WW-64-P-6 (17 tooth gear cut on shaft)

REF. NO.	PART NUMBER	DESCRIPTION	ASSEMBLY USED IN	NO. REQ.	NET WEIGHT	
					LBS	OZ
450	GG-119-3	DRIVEN GEAR - 64 teeth .....	WW-64-P	1	5	2
	GG-122-3	DRIVEN GEAR - 54 teeth .....	WW-64-P-1	1	4	4
	GG-136-5	DRIVEN GEAR - 103 teeth .....	WW-64-P-6	1	6	
451	GG-120-2	DRIVER GEAR - 16 teeth .....	WW-64-P	1		8
	GG-121-2	DRIVER GEAR - 26 teeth .....	WW-64-P-1	1	1	11
452	GG-122-1	DRIVEN SPROCKET - 34 teeth .....	WW-64-P-2	1	3	1
453	GG-123	DRIVER SPROCKET - 10 teeth .....	WW-64-P-2	1		5
454	GJ-15	CHAIN - 1/2" pitch - 40 pitches long .....	WW-64-P-2	1	1	6

**IMPORTANT:** Always give Model, Specification and Serial Numbers as shown on name plate.


**INTERCHANGEABLE PARTS OF WW-64-P, WW-64-P-1, WW-64-P-2, WW-64-P-6  
REDUCTION GEAR ASSEMBLIES**

REF. NO.	PART NUMBER	DESCRIPTION	NO. REQ.	NET WEIGHT	
				LBS	OZ
455	BG-340-S1	<b>MAIN HOUSING ASSEMBLY</b> ..... Includes: ME-92 Bearing.	1	10	
456	BH-144-A-S2	<b>COVER ASSEMBLY</b> for WW-64P, WW-64P-1, WW-64P-2, WW-64P-6 ..... Includes: ME-93 Bearing, PH-265 Oil seal. <b>BH-144-A-S1</b> with ME-93 Bearing and PH-529 Oil seal for obsolete WW-64-N, WW-64N-1, WW-64N-2, WW-64N-6.	1	6	6
458	LO-44	<b>BREATHER</b> .....	1		1
459	ME-92	<b>NEEDLE BEARING</b> (inner) for take-off shaft .....	1		3
460	ME-93	<b>NEEDLE BEARING</b> (outer) for take-off shaft .....	1		4
461	PD-221	<b>LOCK-NUT</b> , 3/4"-16 thread, for driver gear mounting ..... (Not required for WW-64-P-6).	1		2
463	PH-265	<b>OIL SEAL</b> , take-off shaft, for WW-64-P, P-1, P-2, P-6 ..... <b>PH-529</b> for obsolete WW-64-N, N-1, N-2, N-6 .....	1		3
464	PH-333-D	<b>THRUST WASHER</b> for WW-64-P assembly (.022" thick) .....	1		1
	PH-333-E	<b>THRUST WASHER</b> for WW-64-P-6 assembly (.005" thick) .....	2		1
466	QD-623-A	<b>GASKET</b> for cover to housing .....	1		1
467	QD-827	<b>GASKET</b> for housing to gear cover .....	1		1
469	SD-79	<b>TAG</b> for oil instruction .....	1		1
470	WA-69	<b>TAKE-OFF SHAFT</b> for WW-64-P, P-1, P-2, P-6 ..... WA-130 for obsolete WW-64-N, N-1, N-2, N-6 .....	1	2	2
				3	
		<b>STANDARD HARDWARE</b>			
472	PA-289	<b>TAPER PIN</b> , 3/16" dia. x 5/8" long, half taper ..... For cover to housing mounting.	2		1
473	PE-5	<b>LOCKWASHER</b> , 3/8" Positive ..... For housing to gear cover mounting.	4		1
474	PF-51	<b>PIPE PLUG</b> , 1/4" slotted head ..... For optional oil holes in housing.	4		1
475	PH-14	<b>WASHER</b> , 5/16" plain copper ..... For mounting cover to housing.	8		1
476	PL-16	<b>KEY</b> , No. 11 Woodruff, for drive gear mounting ..... (Not required for WW-64-N-6).	1		1
477	PL-50	<b>KEY</b> , No. 16 Woodruff, for driven gear mounting .....	1		1
479	XD-17	<b>SCREW</b> , 5/16"-18 thread x 1" long, hexagon head ..... For mounting cover to housing.	8		1
480	XD-29	<b>SCREW</b> , 3/8"-16 thread x 1-1/4" long, hexagon head ..... For housing to gear cover mounting.	4		1
481	XK-2	<b>PIPE PLUG</b> , 1/4" square head ..... For oil drain and level holes.	2		1
482	XK-21	<b>REDUCER BUSHING</b> , 1/4" to 1/8" pipe ..... For breather mounting.	1		1
483	XK-77-A	<b>STREET ELL</b> , 1/8" x 45° ..... For breather mounting.	1		1

**IMPORTANT:** Always give Model, Specification and Serial Numbers as shown on name plate.

# SK-1430F, SK-1430G, SK-1430H MOTOR-GENERATOR EQUIPMENT

For Models S-10D, S-12D, S-14D (obsolete)  
(SK-1430D on Reverse Side)



SK-1430F – Low mount Motor-Generator without Fuel Tank.

SK-1430G – Motor-Generator with low mounted 1-1/2 Gal. Fuel Tank.

SK-1430H – Motor-Generator with 2-3/4 Gal. Fuel Tank.

Ref. No.	Part Number	Description	No. Net Wt.		
			Req	Lb	Oz
550	BI-380	BRACKET (lower) for motor-generator to crankcase base .....	1	2	
551	BI-380-1	BRACKET (upper) support to tank bracket pad (per SK-1430F) .....	1	2	
	BI-380-2	BRACKET (per SK-1430G)			
	BI-380-3	BRACKET (per SK-1430H)			
553	MD-367-H	PULLEY for motor-generator. Included with motor-generator, but may be purchased separately when required.	1	4	
554	MH-175	DRIVE BELT, 35" long, endless, cog ..	1	6	
556	PG-1182-A	ADJUSTING STRAP .....	1	8	
557	PG-1160	BELT GUARD .....	1	1	
558	VE-799-B	CONTROL PANEL .....	1	8	
560	YB-37Z-S1	MOTOR-GENERATOR 12 volt - 12 amp Delco-Remy No. 1101863 (req. ground). Includes: MD-367H Pulley, furnished by Wisconsin Motor. YB-37V (1101870), repl'd. by YB-37Z-S1.	1	25	


Ref. No.	Part Number	Description	No. Net Wt.		
			Req	Lb	Oz
		<b>NOTE:</b> See Delco-Remy illustration and parts list, on following pages, for motor-generator service parts.			
561	YC-9-F-S1	GROUND SWITCH ASSEMBLY .....	1	2	
		Includes: SD-109 Tag, PE-72 Lockwasher.			
562	YC-10-C	STARTER SWITCH .....	1	4	
563	YE-6	AMMETER (0 - 15 amps) .....	1	6	
		YE-2 (0 - 30 amps) .....		6	
565	YL-352-16	IGNITION WIRE ASSEMBLY .....	1	2	
		Ammeter to regulator. (Batt. term.)			
566	YL-352-19	IGNITION WIRE ASSEMBLY .....	1	2	
		Ground switch to breaker box.			
567	YL-353-4	IGNITION WIRE ASSEMBLY .....	1	1	
		Starter switch to ammeter.			
568	YL-356-20	STARTER CABLE ASSEMBLY .....	1	6	
		Starter switch to motor-generator.			
		(Continued)			

**IMPORTANT:** Always give Model, Specification and Serial Numbers as shown on name plate.

# MOTOR-GENERATOR EQUIPMENT

# SK-1430-D MOTOR-GENERATOR HIGH MOUNT (LESS FUEL TANK) (obsolete)



Ref. No.	Part Number	Description	No. Net Wt.		
			Req	Lb	Oz
<b>STANDARD HARDWARE</b>					
572	PD-77	NUT, 1/4"-20 thread, hexagon steel ..... For mounting starter switch.	2	1	
573	PD-78	NUT, hexagon steel, 5/16"-18 thread .... For adjusting strap at motor-generator.	1	1	
574	PE-3	LOCKWASHER, 1/4" spring lock ..... For mounting starter switch.	2	1	
575	PE-4	LOCKWASHER, 5/16" spring lock ..... 2-for motor-generator to bracket. 1-for adjusting strap.	3	1	
576	PE-5	LOCKWASHER, 3/8" spring lock ..... 4-for motor-generator bracket. 1-for fuel tank bracket.	5	1	
577	PH-30-A	WASHER, 1/4" I.D. x 7/16" O.D. x 1/16" thick, plain steel ..... For control panel mounting.	2	1	
579	PH-209-B	WASHER, 5/16" I.D. x 3/4" O.D. x 3/32" thick, steel ..... For adjusting strap to motor-generator. HF-474, replaced by PH-209-B.	1	1	
580	XA-36	SCREW, 1/4"-20 thread x 3/4" long, indented hex head ..... For mounting starter switch.	2	1	
31	XA-79	SCREW, No. 14 x 1/2" long, self- tapping, round head ..... For belt guard mounting.	3	1	
582	XD-5	SCREW, 1/4"-20 thread x 5/8" long, hexagon head ..... For control panel mounting.	2	1	
583	XD-17-B	CAPSCREW, hexagon head, 5/16"-18 thread x 1" long (heat treated) ..... 2-for adjusting strap to bracket. 2-for motor-generator mounting.	4	1	
586	XD-26-B	SCREW, 3/8"-16 thread x 7/8" long, hexagon head ..... Fuel tank bracket to case.	1	1	
587	XD-32	SCREW, 3/8"-16 thread x 2" long, hexa- gon head (heat treated) ..... For bracket to crankcase. XD-33 (2 1/4" long) replaced by XD-32.	2	2	
588	XD-113	SCREW, 3/8"-16 thread x 2-3/4" long, hexagon head ..... For bracket to crankcase.	2	2	



Ref. No.	Part Number	Description	No. Net Wt.		
			Req	Lb	Oz
590	BI-380-4	BRACKET for motor-generator .....	1	2	
591	MD-367-H	PULLEY for motor-generator .....	1		4
592	MH-198	DRIVE BELT, 36" long, endless, cog ..	1		6
593	PG-1172	BRACKET for adjusting strap .....	1		10
594	PG-1182-B	ADJUSTING STRAP .....	1		6
595	YB-37Z-S1	MOTOR-GENERATOR, 12 volt - 12 amp Delco-Remy No. 1101863, neg. ground. Includes: MD-367H Pulley, furnished by Wisconsin Motor. YB-37V (1101870), repl'd. by YB-37Z-S1.	1	25	
<b>STANDARD HARDWARE</b>					
596	PD-78	NUT, hexagon steel, 5/16"-18 thread .... For adjusting strap.	2	1	
597	PE-4	LOCKWASHER, 5/16" Positive ..... 2-for motor-generator to bracket. 1-for adjusting strap to bracket.	3	1	
598	PE-5	LOCKWASHER, 3/8" Positive ..... For motor-generator bracket.	2	1	
599	PH-22-A	PLAIN WASHER, 3/8" steel ..... For adjusting strap bracket.	2	1	
600	PH-209-B	WASHER, 5/16" I.D. x 3/4" O.D. x 3/32" th'k For adjusting strap to motor-generator.	1	1	
601	XD-17-B	CAPSCREW, hexagon head, 5/16"-18 thread x 1" long, heat treated ..... 2-for adjusting straps. 2-for motor-generator mounting.	4	1	
602	XD-32	SCREW, 3/8"-16 thread x 2" long ..... For bracket to crankcase.	1	2	
603	XD-113	SCREW, 3/8"-16 thread x 2-3/4" long .. For bracket to crankcase.	1	2	

**IMPORTANT:** Always give Model, Specification and Serial Numbers as shown on name plate.

**12 Volt, 12 Amp MOTOR-GENERATOR with REGULATOR**  
**YB-37-Z-S1 (obsolete)** Delco-Remy No. 1101863  
**YB-37-V-S1 (obsolete)** Delco-Remy No. 1101870




NOTE: Parts are interchangeable for both units, except where identified by motor-generator number.

Ref. No.	Part Number	Description	No. Req.
1	18-800213	FRAME, commutator end (for 1101863) Includes: Bearing, wick, dowel pin	1
2	18-1939907	FRAME ASSEMBLY (for 1101870)	1
3	18-1946427	BRUSH	2
4	18-1944373	BRUSH ARM	2
5	18-1916324	BRUSH SPRING	2
6	18-1940421	HOLDER PACKAGE, ground brush	1
7	18-1940422	HOLDER PKG., insulated brush	1
8	18-800212	ARMATURE (for 1101863)	1
9	18-1939904	ARMATURE (for 1101870)	1
10	18-1939889	FIELD COIL, R.H. shunt	1
11	18-1939890	FIELD COIL, L.H. Includes: 18-1858749 term, stud Includes: 18-1858749 term, stud	1
12	18-1939902	POLE SHOE	2
13	18-954378	BALL BEARING, D.E.	1
14	18-1962412	FRAME, D.E.	1
15	18-1959991	COLLAR, D.E.	1
16	18-1858749	STUD, armature term. (incl. bushing)	1
17	18-1858749	STUD, field term. (incl. bushing)	1
18	18-1921362	BUSHING, armature terminal	1
19	18-1939894	BUSHING, arm. term., inside (not ill.)	1
20	18-1955494	BUSHING, field term. (incl. with stud)	1
21	18-1912008	PLATE, bearing retainer, D.E.	1
22	18-1912073	GASKET, bearing retainer plate	1
23	18-1912073	INSULATION, field coil	2
24	18-809763	THRU BOLT	2
25	18-1914816	LOCK WASHER, brush lead screw	2
26	18-1915265	LOCKWASHER, shaft nut, D.E.	1
27	18-1914579	LOCKWASHER, terminal stud	4
28	18-9421424	LOCKWASHER, thru bolt	2
29	18-1915172	NUT, shaft, D.E.	1
30	18-121743	NUT, terminal stud	4
31	18-1914580	SCREW, bearing retainer plate	3
32	18-454329	SCREW, brush lead (6-32 x 5/16)	2
33	18-1968396	SCREW, pole shoe (for 1101863)	2
34	18-1913960	SCREW, pole shoe (for 1101870)	2
35	18-1858753	WASHER, insulating, field term, stud	1
36	18-826319	WASHER, plain, terminal stud	2
37	18-1861591	WASHER, spacer, D.E., inside	1
38	18-124545	WOODRUFF KEY, D.E.	1
39	18-809593	DOWEL PIN, D.E.	1
40	18-904751	BALL BEARING, C.E. (for 1101870)	1
41	18-1929959	BEARING CLAMP, C.E. (for 1101870)	1
42	18-1911485	LEAD WIRE, arm. to regulator	1
43	18-1914185	LEAD WIRE, field to regulator	1
44	18-1947344	SLINGER, grease, D.E.	1
45	18-19118983	REGULATOR service parts list	1
46	18-1927980	COVER	1
47	18-1953902	COVER GASKET	1
48	*18-1878780	ARMATURE	1
49	18-1878493	CONTACT, regulator	1
50	18-1912176	SPRING, regulator armature	1
51	18-1910174	RESISTOR, "F" term. to ground	1
52	18-1944590	ADJUSTING SCREW, regulator arm.	1
53	18-1912159	ADJUSTING SCREW, relay armature	1
54	18-453418	TERMINAL SCREW	4
55	18-1868137	TERMINAL CLAMP	4
56	18-1927982	SCREW, cover mounting	2
57	18-1935031	WASHER, ins., cover mounting	2
58	18-1878505	LOCKWASHER, reg. contact mt'g.	1
59	18-1878516	SCREW, regulator contact mounting	2
60	18-1924764	SCREW, (with L.W.), armature relay	2
61	18-1922599	WASHER, insulating (with bushing) For regulator contact mounting.	2
62	18-1878507	WASHER, ins., reg. contact mt'g.	1
63	18-178451	SCREW, regulator mounting	2
64	18-138579	LOCKWASHER, regulator mounting	2
65	18-1856056	PLAIN WASHER, regulator mounting	2


# BENDIX STARTER MOUNTING and CONTROL PANEL

For Engine Models S-10D, S-12D and S-14D

EEA-106 Starter Motor Mounting



Control Panel Mounting



Ref. No.	Part Number	Description	No.		Net Wt.	
			Req		Lb	Oz
600	BI-370-2	BRACKET for mounting YA-63 starter . . . Refer to page 54 for YA-58 bracket. BI-370 for mounting YA-50 starter . . .	1	1	8	
601	SE-229-A	COVER for starter Bendix .....	1		3	
602	YA-50 (See pg. 52a)  (Alternate) YA-58	STARTING MOTOR (12 volt) ..... Prestolite No. MGD-4102A used in conjunction with BI-370 bracket.  STARTING MOTOR (12 volt) with integral mounting bracket.  NOTE: Refer to following pages for service parts lists of YA-50 and YA-58 Starting Motors.	1		8	
603	YD-296-A	GROUND CONNECTOR ..... (Furnished when specified).	1		1	
604	YL-356-20	STARTER CABLE, to starting switch ..	1		5	
<b>STANDARD HARDWARE</b>						
605	PE-5	LOCKWASHER, 3/8" spring-lock ..... For starter bracket to crankcase.	2		1	
606	XA-73	SCREW No. 7 x 3/8" long, self-tapping round head ..... For starter Bendix cover.	4		1	
607	XD-27	SCREW, 5/16"-18 thread x 1" long, hexagon head ..... For starter bracket to crankcase.	2		1	

Ref. No.	Part Number	Description	No.		Net Wt.	
			Req		Lb	Oz
615	SD-109	TAG for ignition switch .....	1		1	
616	VE-799-C	CONTROL PANEL .....	1		4	
617	YC-9-F-51	GROUND SWITCH ASSEMBLY ..... Includes: SD-109 Tag, PE-72 L.W.	1		2	
618	YC-10-C	STARTER SWITCH .....	1		4	
619	YL-352-21	IGNITION WIRE ASSEMBLY ..... Ground switch to breaker box.	1		2	
620	YL-356-20	STARTER CABLE ASSEMBLY ..... Starter switch to starter.	1		6	
<b>STANDARD HARDWARE</b>						
621	PD-77	NUT, hexagon steel, 1/4"-20 thread ..... For mounting starter switch.	2		1	
622	PE-3	LOCKWASHER, 1/4" spring-lock ..... For mounting starter switch.	2		1	
623	PE-72	LOCKWASHER for ignition switch term.	1		1	
624	PH-84	WASHER, 1/4" I.D. x 1/2" O.D. x 1/16" thick, plain, steel ..... For control panel.	2		1	
625	XA-36	SCREW, 1/4"-20 thread x 3/4" long, indented hexagon head ..... For starting switch.	2		1	
626	XD-5	SCREW, 1/4"-20 thread x 5/8" long, indented hexagon head ..... For control panel.	2		1	

**IMPORTANT:** Always give Model, Specification and Serial Numbers as shown on name plate.










# YA63 STARTING MOTOR

American Bosch part number 02556-25-M030SM


Replaces YA50 Prestolite starting motor beginning with serial number 6073826

Use support bracket BI-370-2



Ref. No.	Part Number	Description	No. Req.
1	9 KT 18939	DRIVE KIT	1
2	9 DV 16375	DRIVE PINION ASS'Y	1
3	9 CP 01447	CAP, DRIVE END	1
4	9 AT 13890	ARMATURE ASS'Y	1
5	9 SC 02620	THRU BOLT	2
6	9 CP 551353AS	CAP, COMMUTATOR END	1
7	9 KT 10900	BRUSH AND SPRING KIT	1

**YA-50 STARTING MOTOR - 12 Volt, 3-1/16" Diameter**  
**Prestolite MGD-4102A (was MGD-4002A)**  
**(Replaced by YA63 beginning with engine serial number 6073826)**



REF. NO. 20, BENDIX DRIVE ASSEMBLY


289709C

Ref. No.	Part Number	Description	No. Req.
1	28-MGD-2101S-2	FRAME and FIELD ASSEMBLY, complete 28-MGD-2101, replaced by 28-MGD-2101S-2 Includes:	1
2	*	BRUSH .....	1
3	*	BRUSH and TERMINAL ASSEMBLY.....	1
4	*	NUT, 1/4"-20 hex. lock, for terminal .....	1
5	28-MGD-18S	SPRING SET for brushes .....	1
6	28-MGD-120S	THRU BOLT PACKAGE .....	1
7	28-MGD-1002	HEAD ASSEMBLY, commutator end .....	1
8	28-MGD-1033B	BRUSH PLATE and HOLDER ASSEMBLY 28-MGD-1033, replaced by 28-MGD-1033B	1
9	28-MGD-1103	HEAD ASSEMBLY, drive end .....	1
10	28-MGD-2106	ARMATURE .....	1
11	28-XA-1221	'O' RING SEAL for armature, 11/16" O.D. 28-HI-226, replaced by 28-XA-1221	1
12	**	THRUST WASHER, D.E., 1/32" thick .....	1
13	**	THRUST WASHER, C.E., .045" thick .....	1
14	**	THRUST WASHER, C.E., 1/32" thick .....	1
		(when required)	

Ref. No.	Part Number	Description	No. Req.
15	**	THRUST WASHER, D.E., .045" thick .....	1
16	**	THRUST WASHER, C.E., .023" thick .....	1
17		NUT, 1/4"-20 hex., for thru bolt .....	2
18		WASHER, 1/4" plain, for thru bolt.....	2
19		LOCKWASHER, 1/4" Skpf., for thru bolt ..	2
20	28-480175	BENDIX DRIVE ASSEMBLY .....	1
		Replaces MGD-1161 and DRF-3002S, inter- changeable and serviced as a unit only.	
*		28-MGD-2032S BRUSH SET for SERVICE	
**		P90-259 ARMATURE THRUST WASHER PACKAGE	
		NOTE: Parts less part number are not serviced separately.	

**IMPORTANT:** Always give Model, Specification and Serial Numbers as shown on name plate.

**YA-58 (12 Volt) STARTING MOTOR ASSEMBLY**  
With integral mounting bracket



Ref. No.	Part Number	Description	No. Req.
10	YS-100	BRUSH SET for service .....	1
11	YS-101	BUSHING, drive end .....	1
12	YS-102	BRACKET and CAP assembly, drive end .. Includes: YS-101 Bushing	1
13	YS-103	DRIVE ASSEMBLY, complete .....	1
14	YS-104	END CAP ASSEMBLY, commutator end .... Includes: Bearing Brush (-) Brush spring Spacing ring	1
15	YS-105	THRU BOLT ASSEMBLY .....	2
16	YS-106	ARMATURE ASSEMBLY .....	1
		Includes: Spacing washers	

**IMPORTANT:** Always give Model, Specification and Serial Numbers as shown on name plate.

# LP-62 series FUEL PUMP

## REPAIR INSTRUCTIONS

For single and two cylinder engine models


PART NO.	ENGINE USED ON
LP-62-A	THD, TJD
LP-62-B	ACN, BKN, AENL
LP-62-C	MTHD
LP-62-D	AGND
LP-62-E	S-7D
LP-62-F	S-10D, S-12D, S-14D
LP-62-G	S-8D, TRA-10D, TRA-12D

The fuel pump, like all other parts of the engine, is subject to wear and you will find that any time after 500 hours of use, its efficiency will gradually decrease. This is indicated by the engines faltering at high speeds or when heavy loads are suddenly applied. The pump can easily be restored to its normal efficiency by the installation of a Wisconsin LQ-51 Diaphragm Kit.

1. Disconnect fuel lines from pump and remove fuel strainer if mounted to pump. Remove fuel pump from engine housing by taking out the two mounting screws.
2. File a groove across a point at the union of castings (9 and 10). This is a positive location of the fuel INLET and OUTLET positions when reassembling. Remove four head to bracket screws (12) and remove fuel head (10).
3. Turn fuel head (10) over, remove and discard both valve assemblies, noting their positions.
4. Clean fuel head thoroughly with kerosene or diesel fuel and a fine wire brush.

5. Hold fuel head (10), with diaphragm surface up, place two valve gaskets (4) into cavities where valves were removed. Press valve assemblies (5) in evenly without distortion, and stake in place.
6. Set fuel head assembly aside and proceed to rebuild lower diaphragm section.
7. Insert the end of a small screw driver into the coils of rocker arm spring (11), remove and save.
8. Hold mounting bracket (9) in the left hand, with the rocker arm toward your body and the thumb nail on the end of link (8). With the heel of right hand on diaphragm (2), compress the diaphragm spring (3), and at the same time turn in a clockwise direction 90°. This will unhook the diaphragm from link (8) so it can be removed.
9. Clean the mounting bracket (9) with kerosene or diesel fuel and a fine wire brush.
10. Place the new diaphragm operating spring (3) into bracket (9). Repeat in reverse order paragraph eight, using the new diaphragm. Replace rocker arm spring (11) removed in paragraph seven.
11. Mount this assembly back on the engine in the position from which it was removed, using the new flange gasket (13), which is the last piece of the repair kit.
12. Crank the engine over to a position where the diaphragm (2) is laying flat on the mounting bracket (9). Place the fuel head (10) back in position so that the indicating marks of step one are in line, and start the four head screws approximately three turns. Again, crank the engine over to a position where diaphragm (2) is pulled down into mounting bracket (9) to its lowest position. Securely tighten the four head screws (12).
13. Mount fuel strainer to fuel pump, if applicable, and connect fuel lines.

NOTE: The LQ-51 Diaphragm Kit and the parts included therein, which are identified by an asterisk (\*), are the only parts of the fuel pump available for service.



Ref. No.	Description	No. Req.
1	ROCKER ARM .....	1
* 2	DIAPHRAGM ASSEMBLY .....	1
* 3	DIAPHRAGM SPRING .....	1
* 4	VALVE GASKETS .....	2
* 5	VALVE and CAGE ASSEMBLY .....	2
6	PIN for rocker arm .....	1
7	SPRING CLIP for rocker arm .....	1
8	LINK for diaphragm spring .....	1
9	MOUNTING BRACKET .....	1
10	FUEL HEAD .....	1
11	SPRING for rocker arm .....	1
12	SCREW and WASHER for head mounting .....	4
*13	GASKET for mounting flange .....	1

# REWIND (Recoil) STARTER

RWS 116  
RWS 117  
RWS 118

For Wisconsin Engine Models S-12D and S-14D

## Operating Instructions — Repair — Parts List




FIG. 1

### PRINCIPLES OF OPERATION

A recoil spring, connecting the pulley to the housing, provides tension for actuating the starter, and it rewinds the rope on to the pulley whether the engine starts or not.

Three dogs (pawls) are mounted in a cluster to the starting pulley, around a dog cam attached to a shaft in the housing. As the rope handle is pulled to start the engine, the dogs are forced outward as they act against the contour of the stationary mounted cam. In this outward action the dogs engage with teeth in a flywheel mounted drive hub to turn the engine over.

When the engine starts and the 'T' handle returns, the dogs back out of the drive hub teeth, as the pulley rewinds in the opposite direction, and they revert back to an inactive position by means of the cam and individual dog return springs.

### 'T' HANDLE LOCATION, Fig. 2

The starting handle can be located in any of three locations with the standard location being toward the left side of the engine, pulling from an approximate 10 o'clock position.

Either of the two optional locations can be obtained by simply removing the three mounting nuts and rotating the housing 120° in either direction. *Caution:* Before




FIG. 2

tightening the mounting nuts the starter will have to be centered with the drive hub per *Fig. 7*, paragraph *H* on page 3.

### OPERATING INSTRUCTIONS

1. *To start engine;* open fuel valve and close carburetor choke. Pull engine over against compression. Let rope rewind into starter slowly. Pull firmly and rapidly to start engine. (Repeat procedure if necessary). After engine starts, open choke fully.
2. Always maintain your hold on the starter handle and allow it to return slowly.
3. Pull the starter handle so that the rope remains in a straight line through the handle and guide.
4. *Do not* jerk the cord out to its very end in an unnecessary rough manner. Use a smooth but forceful pull.
5. *Do not* let go of starter handle allowing it to snap back against the starter.
6. *Do not* attempt to pre-load starter spring unnecessarily. Units are properly adjusted at the factory so that the outward pull of the starter is stopped by the end of the cable not the spring.

### MAINTENANCE AND REPAIR

*Oil and dirt*, if allowed to accumulate in and around the the starter, will cause wear and eventual failure of not only the starter parts, but engine parts as well.

Do not allow internal rotating screen and housing fins to become "clogged up" with dirt. Brush clean to allow proper air flow to reach the engine.

Inspect rope for wear — replace before it breaks at a critical time.

If engine does not turn over as rope is pulled out, starter dogs are not engaging with drive hub teeth.

If rope does not rewind; rope or pulley may be binding — insufficient spring tension — spring disengaged or broken.

To overhaul the rewind starter, follow the disassembly and assembly procedures in the following 'Repair Instructions'. **Rope replacement** can be accomplished without completely disassembling the starter. See paragraph D.

## REPAIR INSTRUCTIONS

In order to do any repair work on the rewind starter, it is advisable to secure the starter housing either in a vise, or to a work bench by means of a 'C' clamp.

### DISASSEMBLY

#### A. REMOVE HANDLE and ROPE, Fig. 3

Pull rope out about two feet and tie knot to prevent rope from rewinding into pulley. Extract metal handle reinforcement (129) from handle (128) and untie or cut off end knot. Remove handle and reinforcement from rope, and untie knot that kept the rope from rewinding into the pulley. PULL rope all the way out (about 6 feet) and at the same time hold the starter housing (127), with thumb pressing against pulley assembly (137) to prevent rewinding. Pull the rope knot (visible thru square opening in pulley) and the rope will slide out through rope bushing in housing and hole in the pulley.

Carefully release thumb pressure and the pulley will completely unwind. At this point the main recoil spring is in a relaxed position.

#### B. REMOVE PULLEY and SPRING, Fig. 3

Remove cam center screw (130), dog cam (135), brake spring (134) and washer (125).

Prevent recoil spring from escaping from housing by carefully lifting pulley about 1/2 inch and then detaching inside spring hook from pulley, with a screw driver. **Note:** If spring should escape, it can easily be replaced into cover by coiling in the turns. See Fig. 6, for proper direction of spring coiling. If it is necessary to remove spring, start with the inside loop and carefully pull out one loop at a time while holding back rest of turns. When replacing spring, note the position of spring hooks in Fig. 6. Engine rotation is clockwise, viewed from starter end.

#### C. REMOVAL of DOGS, Fig. 3

Remove dog retainer clips (133) using a screw driver or other pointed tool. The dogs (132) and springs (131) can then be lifted off the axis pins.

Dogs and springs can be removed and replaced without removing rope, recoil spring or cam retainer screw.

#### D. ROPE REPLACEMENT, Fig. 3, 4, 5

If it is only necessary to replace the rope, the starter need not be completely disassembled.

Assuming the rope has broken, remove what ever remains of the rope from the starter. Tie knot at end of new rope. Turn the pulley in starter counter clockwise until it stops (about 6-7 turns). Allow the pulley to rotate slightly in the opposite direction (clockwise) until the hole in the pulley is in line with the rope bushing in the housing. Lock sheave in this position by placing a screw driver between two of the housing support ribs and wedging the end of the screw driver under the dog cam and against the dog, see Fig. 4. Thread rope through hole in pulley and through rope bushing in housing. Pull rope completely through until the knot in end of rope (previously tied) can be tucked




FIG. 3






FIG. 4

into the *square pocket* in the pulley, see Fig. 5. Allow the rope to recoil into the pulley about 2 feet, then tie a *retaining knot* in the rope to prevent it from being completely rewound into the pulley. Install the 'T' handle (128) on the rope, then the handle insert (129). Tie a knot at end of rope and tuck it into the handle insert, then assemble insert into the rubber 'T' handle. Remove the retaining knot and allow the rope to recoil completely.

**E. RECOIL SPRING REPLACEMENT, Fig. 6**

Spring holders furnished with replacement springs simplify the assembly procedure. Place *recoil spring* in proper position as shown in Fig. 6, with the outside loop hooked around the *anchor post*. Then press spring into *housing cavity* thus releasing the spring holder. A few drops of SAE 20 or 30 oil should be applied to spring and light grease on housing shaft.

**REASSEMBLY**

**F. ASSEMBLY of PULLEY, Fig. 6**

After recoil spring has been installed in housing, mount pulley. Push housing and pulley together with a twisting motion so that the *hook* on end of spring engages the *notch* in pulley. When this occurs, the pulley will seat properly in the housing.




FIG. 5




FIG. 6

**G. ASSEMBLY of DOG GROUP, Fig. 3**

Assemble brake washer (125), brake spring (134), dog cam (135), cam and center screw (130). Torque center screw 115-130 inch pounds. Install three dog springs (131) over the axis pins on the pulley and seat in the pockets. Mount the three dogs (132) on the same pins on pulley. Make sure that the *dog springs are actuated* as the dogs are positioned – to insure that the dogs are held in against the cam plate (135). Install three dog retainers (133). *Note:* When ever the dog retainers (133) are removed they should be replaced with new parts.

**H. REWIND STARTER ALIGNMENT, Fig. 7**

Mount rewind starter to support ring studs with 'T' handle in required starting position. Place the three plain washers, lockwashers and nuts on studs and *hand tighten only* – for alignment purposes.

Proper *alignment* of the starter is obtained by pulling out the 'T' handle until a substantial resistance, indicating starter engagement, is obtained. This automatically centers the starter to the *drive hub*. Hold starter in this position and securely tighten the three mounting nuts. *The starter will become damaged if it is not centered properly.* The engine is now ready to start.





FIG. 7

# RWS 116 REWIND STARTER ASSEMBLY – SERVICE PARTS LIST


RWS 117, RWS 118 Same as RWS 116 except T-Handle in alternate locations, see Fig. 2.



Ref. No.	Part Number	Description	No. Req.
100	SE 337-1	FLYWHEEL SHROUD replaces standard ..... Same as std. shroud except with three 3/8 inch holes on a 8-1/2 inch bolt circle for mounting starter.	1
101	PG 1300	SUPPORT RING .....	1
102	SE 334	SCREEN, rotating .....	1
103	U 283	REWIND STARTER ASSEMBLY .....	1
104	UC 204	DRIVE HUB .....	1
<b>STANDARD HARDWARE</b>			
106	PD 78	NUT, 5/16-18 thread, hexagon steel ..... For rewind starter mounting.	3

Ref. No.	Part Number	Description	No. Req.
107	PE 3	LOCKWASHER, 1/4" spring lock ..... For drive hub to flywheel mounting.	3
108	PE 4	LOCKWASHER, 5/16" spring lock ..... For rewind starter mounting.	3
109	PH 14 D	WASHER, 5/16" x 19/32" O.D., plain steel .... For rewind starter mounting.	3
110	PH 293 A	WASHER, 1/4" x 7/16" O.D., plain steel ..... For drive hub to flywheel mounting.	3
111	XD 7	SCREW, 1/4"-20 x 1" long, hex head ..... For drive hub to flywheel mounting.	3

# U 283 REWIND STARTER – SERVICE PARTS LIST



Ref. No.	Part Number	Description	No. Req.
125	27-504-015-0	WASHER, brake spring .....	1
126	27-504-022-0	ROPE, No. 6 x 74" long .....	1
127	27-504-116-0	HOUSING ASSEMBLY .....	1
128	27-508-008-0	T HANDLE .....	1
129	27-508-009-0	REINFORCEMENT, T handle .....	1
130	27-525-003-0	SCREW, cam center .....	1
131	27-525-007-0	DOG SPRING .....	3

Ref. No.	Part Number	Description	No. Req.
132	27-525-008-0	DOG .....	3
133	27-525-012-0	DOG RETAINER CLIP .....	3
134	27-525-013-0	BRAKE SPRING .....	1
135	27-526-001-0	DOG CAM .....	1
136	27-526-003-0	RECOIL SPRING .....	1
137	27-526-504-0	PULLEY and BEARING assembly .....	1

ZENITH MODEL 1408

# CARBURETOR

For WISCONSIN Engine Models S-10D, S-12D, S-14D

## OPERATION and SERVICE

### DESCRIPTION

The 1408 Series Carburetor is a horizontal "balanced" type with concentric fuel bowl, a single "doughnut"-shaped float, fixed main jet, three-position, spring-loaded choke plate, an idle adjusting needle and throttle stop screw. The venturi is cast integral with the throttle body and the idle tube, main discharge tube and well vent tube are pressed permanently into an elongated boss on the throttle body. This boss serves as the mounting support for the fuel bowl, as well as the main jet. In the "balanced" type carburetor, all air for float chamber ventilation, well ventilation and for idle and main jet operation must enter through the air cleaner. In this design, any restriction in the air cleaner will have a minimum effect upon the fuel-air mixture admitted to the engine.

The **FUEL SYSTEM** controls the level of fuel in the float chamber (fuel bowl) at all times and under all conditions of operation. The Fuel Supply System consists of: the fuel inlet fitting, float chamber, fuel valve (needle and seat), doughnut-shaped float with double hinges, and a single float lever.

The **IDLE SYSTEM** supplies the fuel-air mixture for idle and off-idle (low part - throttle operation). The Idle System consists of: idle tube, idle air bleed, connecting channels, three idle discharge hole, idle adjusting needle and throttle plate.

The **HIGH SPEED (main metering) SYSTEM** supplies the fuel-air mixture for part throttle to full throttle operation. The High Speed System consists of: venturi, discharge nozzle, metering well and tube, well vent, main jet and connecting channels.

The **CHOKE SYSTEM** provides a richer mixture of fuel and air for starting a cold engine. The Choke System consists of: an external choke lever and detent spring, choke shaft and choke plate.

### OPERATION

#### FUEL SUPPLY SYSTEM (Fig. 1)

Fuel under pressure is supplied to the carburetor through the fuel inlet, to the fuel valve (needle and seat), and on to the float chamber. With fuel in the float chamber, the float automatically regulates the opening through the fuel valve to maintain a specified level of fuel in the float chamber even though the fuel flow demands vary with engine speed and load.

#### IDLE SYSTEM (Fig. 2)

The fuel for idle operation is drawn from the metering well through the idle tube calibration and mixed with air entering through the idle air bleed in the channel leading to the idle discharge holes. At low idle speed, the throttle plate is positioned so that only the #1 idle discharge hole is exposed to engine vacuum. Since the #2 and #3 idle holes are exposed to the air entering the carburetor, air is admitted through idle holes #2 and #3 to be mixed with the fuel-air mixture in idle channel before being discharged through the #1 idle discharge hole into the intake manifold. Opening the throttle plate slightly exposes the #2 idle discharge hole to engine vacuum to feed more fuel-air mixture




Fig. 1 FUEL SUPPLY SYSTEM




Fig. 2 IDLE AND CHOKE SYSTEMS

into the engine. As the throttle is advanced slightly, the #3 idle discharge hole is also exposed to engine vacuum, increasing the fuel-air supply to the engine still further. At this throttle position, any further throttle advance brings the high speed system into operation. The idle adjusting needle regulates the fuel-air mixture flowing through the #1 idle discharge hole. Turning the idle needle valve IN (clockwise) results in a leaner mixture. Turning it OUT (counter-clockwise) provides a richer mixture. The idle speed is set by adjusting the throttle stop screw and not by the idle adjusting needle.

### CHOKE SYSTEM (Fig. 2)

Before cranking the engine, the carburetor throttle should be opened just enough to expose all three idle discharge holes to engine vacuum. The choke should be held fully closed during cranking and opened slightly (one notch) shortly after the engine starts. As the engine warms up, the choke should be opened to the third notch, wide-open, and the throttle should be returned to the low idle position.

### HIGH SPEED SYSTEM (Fig. 3)

Fuel for the off-idle to full throttle range of operation is supplied from the fuel bowl through the main metering jet to the discharge nozzle, where it is mixed with air taken in from the air intake in front of the venturi and with air drawn into the discharge nozzle from the chamber surrounding the venturi. This mixture of fuel and air then passes through the discharge nozzle into the air stream at the throat of the venturi. To insure the correct mixture ratio, a small amount of air is added from the well vent or high speed bleed, through the air bleed holes located in the wall of the metering well at various levels. By introducing air into the system below the fuel level in the fuel bowl, the surface tension of the fuel is reduced, enabling the fuel to flow at lower suction. At high suction, the air from the well vent proportionately reduces the flow of fuel to provide a correctly balanced mixture ratio at all engine speeds and loads.




Fig. 3 HIGH SPEED SYSTEM

## SERVICE AND REPAIR PROCEDURE

### IDENTIFY CARBURETOR

Check the numbers on the metal identification disc pinned to the top of the throttle body or indented in it. The plain number is the Zenith assembly number, the number with the letter "L" pre-fixed to it is the engine manufacturer's part number, for the complete assembly.

### EXPLODED VIEW (Fig. 4)

The exploded view identifies the serviceable component parts of the carburetor and shows their relationship to the complete assembly. Use the key numbers on the exploded view to identify and locate parts when performing both the disassembly and assembly operations.

## DISASSEMBLY

### REMOVAL OF FUEL BOWL

1. With carburetor inverted, loosen main jet (18). Remove main jet assembly, washer (19) and fuel bowl (12).
2. Inspect main jet (18) for wear.

### DISASSEMBLY OF THROTTLE BODY

1. Stand throttle body (1) on end and use scribe or heavy wire to press float axle (10) out of float hinges. Remove axle and float (9).
2. Hold hand under fuel inlet and turn throttle body to horizontal position. Catch fuel valve, pin and spring (parts of 20) as they fall from seat.
2. Remove idle adjusting needle (5) and spring (6) by unscrewing them (counterclockwise). Remove throttle stop screw (7) and spring (8) in the same way.
4. Lay throttle body down with fuel bowl side up. Use large screwdriver to remove fuel valve seat (part of 20) and washer (21) from fuel inlet port.
5. Remove bowl to body gasket (11).
6. Close choke plate (16), and use small screwdriver to remove screws (17). Slide choke plate out air intake opening and choke shaft and lever (15) out shaft hole. Do NOT remove choke detent spring (24) unless it is damaged and must be replaced.
7. Close throttle plate (13), and use small screwdriver to remove screws (14). Slide throttle plate out manifold opening and throttle shaft and lever (23) out shaft hole. Use small screwdriver to pry seal retainer (3) and seal (2) off shaft hole boss. Do NOT remove shaft hole plugs (4) unless they are damaged and must be replaced.

### CLEANING

Thoroughly clean all metal parts in Bendix Metalclene or Speedclene and rinse in cleaning solvent. Blow out all passages in throttle body and fuel bowl with reduced air pressure. Be sure all carbon deposits have been removed from throttle bore and idle discharge holes. Reverse the flow of compressed air through all passages to insure the removal of all dirt. NEVER USE A DRILL OR WIRE TO CLEAN OUT JETS OR IDLE HOLES.

### INSPECTION OF PARTS

1. Float Assembly - Replace if loaded with gasoline, damaged or if float axle bearing is worn excessively. Inspect float lever for wear at point of contact with fuel valve needle. Replace if wear is excessive.
2. Float Axle - Replace if any wear has occurred on the bearing surface.
3. Fuel Valve (Needle & Seat) Assembly - Replace as a complete unit. Wear of any of these parts can seriously affect the operation of the float.
4. Idle Adjusting Needle - Inspect tapered end of the needle to make sure it is smooth and free of grooves. Replace if pitted or grooved.




Fig. 4 EXPLODED VIEW

5. Gaskets, Seal and Retainer — Replace all gaskets, throttle shaft seal and retainer each time the carburetor is overhauled.

### REASSEMBLY

#### ASSEMBLY OF THROTTLE BODY

1. Slide throttle shaft and lever (23) into seal retainer (3) and seal (2). Insert shaft into throttle shaft hole at manifold end of throttle body (1). Seat shaft in hole on opposite side of throttle bore and press seal and retainer firmly against shaft hole boss.
2. Rotate throttle lever so flat center section faces out manifold opening. Install throttle plate (13) with screws (14), using small screwdriver.
3. Slide choke shaft and lever (15) into choke shaft hole and seat in hole on opposite side of air intake bore.
4. Rotate choke shaft so flat center section faces out intake opening. Install choke plate (16) with screws (17), using small screwdriver.
5. Lay throttle body down with fuel bowl side up and install bowl to body gasket (11).
6. Install washer (21) and fuel valve seat (part of 20). Use large screwdriver to tighten seat to 100 in-lbs. Insert valve, spring and pin (parts of 20) into seat.
7. Install float (9) and float axle (10) on support brackets of throttle body. Check operation of the float to be sure the hinge and axle do not bind and that the float moves in a perpendicular direction.
8. Install throttle stop screw (7) and spring (8). Adjust screw to open throttle slightly but not far enough to uncover #2 idle discharge hole, see Fig. 2.
9. Install idle adjusting needle (5) and spring (6). Screw needle IN (clockwise) until it seats lightly against the #1 idle discharge hole, then back it out 1½ turns as a preliminary idle adjustment.

### FLOAT SETTING

1. With fuel bowl removed, set depth gauge to dimension recommended in illustration, Fig. 5.
2. Hold throttle body assembly in an inverted position and at the same time, support float so that tab or float lever just contacts fuel needle valve without any pressure or weight.
3. Place depth gauge in position as illustrated in Fig. 5.
4. CHANGING FLOAT LEVEL POSITION
  - a. If float position is not to the dimension shown by depth gauge, remove float and bend tab (or lever) that contacts the needle pin (use long-nose pliers — close to the float body), until correct dimension is obtained. Reassemble float to throttle body and re-check float level position.





Fig. 5, FLOAT SETTING

#### ASSEMBLY OF FUEL BOWL TO THROTTLE BODY

1. Assemble washer (19) on main jet (18) and install fuel bowl (12) on inverted throttle body, using care to avoid damage to the float. Screw main jet with washer into throttle body boss, using 1/2" wrench and tighten to 100 in. lbs.

Assembly is now completed.

**SERVICE PARTS LIST**  
**ZENITH SERIES 1408 CARBURETOR**  
For Wisconsin Engine MODELS S-10D, S-12D and S-14D




CARB. REF. NO.	ZENITH ASSEMBLY NO.	WISCONSIN PART NO.
1	13022-B	L-86-A-S1
2	13027-B	L-86-B-S1
3	13040-B	L-86-C-S1
4	13064-A	L-86-D-S1
5	13137-A	L-86-E-S1
6	13138-A	L-86-F-S1
7	13155-A	L-86-G-S1
8	13208-A	L-86-H-S1
9	13224-A	L-86-J-S1
10	13225-A	L-86-K-S1
11	13187-A	L-86-L-S1
12	13188-A	L-86-M-S1
13	13322-A	L-86-Q-S1
20	13385-A	L-95-S1
21	13417-A	L-95-A-S1
22	13395-A	L-95-B-S1
23	13561-A	L-95-C-S1
25	13557-A	L-95-E-S1
26	13573-A	L-95-F-S1
28	13648-A	L-95-H-S1

NOTE: Parts are identical for all carburetors, except those identified by carburetor Ref. No.

Item No.	Part Number	Description	No. Req.
1		THROTTLE BODY - Not serviced separately	
2	93-T48-9 †	SEAL - Throttle Shaft	1
3	93-C116-33 †	RETAINER - Throttle Shaft Seal	1
4	93-CR-137-19	CUP PLUGS - 1/4"	2
5	93-C46-49	NEEDLE - Idle Adjustment	1
6	93-C111-155	SPRING - Idle Adjustment	1
7	93-T1858-10	SCREW - Throttle Stop, #8-32 thread	1
8	93-C111-10	SPRING - Throttle Stop Screw	1
9	93-C85-129	FLOAT & HINGE ASSEMBLY	1
10	93-C120-75 †	AXLE - Float	1
11	93-C142-80 †	GASKET - Bowl to body	1
12	93-C3-132	FUEL BOWL for all except 5 and 6	1
	93-C3-132A	FUEL BOWL ASSEMBLY for 5, 6 Includes: (Not illustrated) 93-C104-27 Drain valve assembly	1
		93-T75-3 "O" Ring seal	1
		93-C111-211 Spring	1
		93-CR115-13 Spring retainer	1
13	93-C21-219	PLATE - Throttle	1
14	93-T31555-4	SCREW & WASHER throttle plate, 1/8"-40 thrd.	2
15	93-C108-278	LEVER & SHAFT ASSEMBLY - Choke For 1, 2, 3, 4, 5, 6, 7, 20, 21, 23, 26.	1
(Not illust.)	93-C108-290	LEVER & SHAFT ASSY. - Choke for 8, 22	1
	93-C105-286	CHOKE SHAFT for 9, 10, 11, 12, 13, 25, 28	1
	93-CR106-3A	CHOKE LEVER for 9, 10, 11, 12, 13, 25	1
	93-T22-58	LEVER NUT for 9, 10, 11, 12, 13, 25, 28	1
	93-T41-10	CHOKE LEVER LOCKWASHER For 9, 10, 11, 12, 13, 25, 28.	1
16	93-C102-147	PLATE - Choke 93-C101-89 (with poppet valve), replaced by 93-C102-147.	1
17	93-T31555-4	SCREW - Choke Plate, 1/8"-40 thread	2

Item No.	Part Number	Description	No. Req.
18		MAIN JET ASSEMBLY - Fixed For carburetors 1, 2, 5, 9, 10	1
	93-C52-39-20	For 3, 4, 6, 7, 8, 11, 12, 13.	
	93-C52-39-23	For 20, 21, 22, 23, 25, 26, 28.	
18A	(Obsolete)	ADJUSTABLE MAIN JET ASSEMBLY Used on carburetors previous to the Letter designation following the above listed ZENITH carburetor assembly numbers. 93-C71-64-24 For carburetors 1, 2, 5, 9, 10. 93-C71-64-30 For 3, 4, 6, 7, 8, 11, 12, 13. 93-C71-64-34 For 20, 21, 22, 23.	
19	93-T56-23 †	WASHER - Main jet adjustment	1
20		FUEL VALVE & SEAT ASSEMBLY 93-C81-50-2-25 † For carburetors 1, 3, 8, 9, 11, 21, 22, 26, 28	1
	93-C81-50-35 †	For 2, 4, 5, 6, 7, 10, 12, 13, 20, 23, 25	1
21	93-T56-80	GASKET - Fuel valve seat for 1, 3, 8, 9, 11, 21, 22, 26, 28	1
	93-T56-70	GASKET - For 2, 4, 5, 6, 7, 10, 12, 13, 20, 23, 25	1
22	QC-12-A †	FLANGE GASKET	1
23	93-C29-1463	THROTTLE SHAFT & LEVER ASSEMBLY For all except 7 and 13.	1
	93-C29-1565	THROTTLE SHAFT & LEVER ASSEMBLY For 7, 13.	1
24	93-C111-208	SPRING - Choke lever detent For 1, 2, 3, 4, 5, 6, 7, 20, 21, 23, 26.	1
		†PARTS INCLUDED IN REPAIR KIT LQ-44 Repair Kit for 1, 3, 8, 9, 11, 21, 22, 26, 28. LQ-45 Repair Kit for 2, 4, 5, 6, 7, 10, 12, 13, 20, 23, 25.	

# FLYWHEEL ALTERNATOR



## with solid state regulation

12 Volt - 10 amp and 25 amp Systems For  
WISCONSIN Single, Two and Four Cylinder Engine Models

### DESCRIPTION of Change

Beginning with engine serial No. 5188288, a new *two module* flywheel alternator system replaces the previously furnished three module system, that included an isolation diode module, and the two unit system without the isolation diode.

The *isolation diode* module was incorporated into the old system to eliminate battery discharge problems during shut down, cranking and idling.

### INTERCHANGEABILITY


The *Regulator module* was not changed and is completely interchangeable between the new and old systems. The *Rectifier module* and *Stator assembly* have been modified to incorporate the advantages of an isolation diode without adding a third module. These new parts are *not* interchangeable with the old unless both rectifier and stator are replaced simultaneously. The new system has a *three prong* plug connector between the rectifier and stator - the old system has a two prong connector.

### DESCRIPTION and OPERATION

This flywheel alternator is of the permanent magnet type and has *no brushes, commutator, belts or adjustments*. A series of coils (stator) is mounted to the engine gear cover, and the magnetic flux is provided by a permanent magnet in the flywheel which rotates around these stationary coils. Only four components make up this light weight space saving system; a *flywheel* with magnetic rotor, *stator*, *rectifier* module and *regulator* module.

The *center-tap* rectifier arrangement prevents damage to the alternator system when arc welding, because the winding acts as a choke and its inductance prevents the transient voltage from damaging the diodes.

Since the physical appearance of both 10 amp and 25 amp alternator systems are very similar, the 25 amp



319423C-1

*unit* can be distinguished from the 10 amp unit by the ammeter calibrations, and by a 14 gage green wire in place of a 16 gage red wire, from the ammeter to the stator-regulator connector.

**PRECAUTIONS** to be exercised in the use of this flywheel alternator:


1. **Do Not** reverse battery connections. This is for a *negative ground* system only.
2. Connect booster batteries properly - positive to positive and negative to negative.
3. **Do Not** polarize the alternator.
4. **Do Not** ground any wires from stator or modules which terminate at connectors.
5. **Do Not** operate engine with battery disconnected from system.
6. Disconnect at least one battery lead if a battery charger is used.




## WIRING CIRCUIT

The *fool-proof* type connectors used prevent incorrect wiring from the stator to the rectifier and regulator modules. To disconnect plugs, squeeze outer ends of receptical and pull apart.

The rectifier is insulated from ground, but the stator and regulator module are grounded to the engine thru their mounting surface. The regulator module therefore should not be removed and mounted at some remote location. This is a *negative ground circuit*. Connect ground strap from negative post of battery to starting motor flange, or good clean grounding surface on engine.



WIRING DIAGRAM  
For Single Cylinder Models



WIRING DIAGRAM  
For Two and Four Cylinder Models

## SERVICE PROCEDURE:

Prior to electrical testing, a thorough visual inspection should be made to eliminate conditions that may be interpreted as a defected alternator. Examine leads for broken or loose connections, and make sure modules are securely mounted. The *regulator module* must be mounted to a metal surface for grounding purposes, while the *rectifier module*, although insulated from ground, should be securely mounted for heat dissipation. The mounting surfaces must be clean and free of contaminants, oil, grease, etc. When assured that the problem is with the alternator, follow the tests outlined in 'Trouble Shooting'.

## TROUBLE SHOOTING

### 10 and 25 amp Flywheel Alternator

Problem: Battery Overcharge	Possible Cause & Remedy
Test 1.0 With engine running at full RPM, check battery voltage w/ DC Voltmeter.	
1.1 If voltage is over 15.0	1.1 Regulator not functioning properly. Replace module.
1.2 If voltage is under 15	1.2 Alternator functioning properly. Check battery condition.

Problem: Low/No Charge	Possible Cause & Remedy
Test 1.0 With engine running at full RPM, check battery voltage w/ DC meter. If voltage is greater than 14 volts, place * load on battery to reduce voltage below 14 volts.	
1.1 If the charge rate increases -	1.1 Alternator functioning properly. Battery was fully charged.
1.2 If the charge rate does not increase -	1.2 Proceed with Test 2.0.


\* Place as many 12 volt light bulbs across battery as required to reduce voltage below 14 volts. A carbon pile resistor may be used in place of bulbs.

Problem: Low/No Charge	Possible Cause & Remedy
<p>Test 2.0 Conditions and procedure the same as Test 1.0 except the regulator module is disconnected.</p> <p>2.1 If the charge rate increases -</p> <p>2.2 If the charge rate does not increase-</p> <p>Test 3.0 Test conditions and procedure the same as 1.0 except with new rectifier module plugged in.</p> <p>3.1 If the charge rate increases -</p> <p>3.2 If the charge rate does not increase-</p> <p>Test 4.0 With engine stopped, unplug all connectors between modules and stator. Start engine and run at 2400 RPM. With AC voltmeter check voltage between each of the black stator leads and ground.</p> <p>4.1 If one of the two voltages is zero or they are over 10% apart -</p>	<p>2.1 Regulator was at fault. Replace regulator module.</p> <p>2.2 Regulator is not at fault. Continue with Test 3.0.</p> <p>3.1 Rectifier module at fault. Permanently install new rectifier module.</p> <p>3.2 Continue with Test 4.0.</p> <p>4.1 The stator is faulty and should be replaced.</p>

Further testing can be done on the component level with the engine stopped, and the stator and module connections including output lead uncoupled.

### TO CHECK STATOR

Use an ohmmeter and check continuity as follows:



**NOTE:** Wire numbers indicated for probe connections are for convenience only and are not indicated on the connectors.

### For 10 amp unit STATOR

METER PROBE CONNECTIONS	METER VALUE	REPLACE STATOR	
+ -			
Black #1 to Black #2	APPROX. 2.0 ohms	0 Indicates Short Circuit. ∞ Indicates Open Circuit.	
Black #1 to Eng. Gnd.			1.0 ohm
Black #2 to Eng. Gnd.			1.0 ohm
Black #1 to Red			3.0 ohms
Black #2 to Red			1.0 ohm

### For 25 amp unit STATOR

METER PROBE CONNECTIONS	METER VALUE	REPLACE STATOR	
+ -			
Black #1 to Black #2	APPROX. 0.40 ohm	∞ Indicates Open Circuit.	
Black #1 to Eng. Gnd.			0.20 ohm
Black #2 to Eng. Gnd.			0.20 ohm
Black #1 to Red			3.20 ohms
Black #2 to Red			2.80 ohms

### STATOR IDENTIFICATION:

10 amp - 3/8" wide flange      25 amp - 5/8" wide flange

### TO CHECK RECTIFIER MODULE, Part No. YJ-68

The same module is used for both the 10 amp and 25 amp systems. It can be distinguished from the regulator by the three lead wires instead of two and the identification decal. Use an ohmmeter and static check continuity as follows:

METER PROBE CONNECTIONS	METER INDICATION
+ -	
White lead to Black #1	No Continuity
Black #1 to White lead	
White lead to Black #2	No Continuity
Black #2 to White lead	

**Note:** Continuity shall be in one direction only. If readings are not as indicated, replace module.

### TO CHECK REGULATOR MODULE, Part No. YJ-60

The same Regulator module is used for both the 10 amp and 25 amp systems. Use an Ohmmeter and static check as follows:

METER PROBE CONNECTIONS	METER INDICATION	REPLACE MODULE
+ -		
Red to Eng. Gnd.	No Continuity	Continuity
Eng. Gnd. to Red		
Red to Black	Continuity	No Continuity
Black to Red		
Black to Eng. Gnd.		
Eng. Gnd. to Black		


### AMP OUTPUT regulated by engine speed

MODEL	MAXIMUM ENGINE SPEED	10 AMP SYSTEM	25 AMP SYSTEM
S-12D, S-14D	3600 RPM	10 amps	25 amps
AENL, TJD			
AGND	3200 RPM	10 amps	23 amps
VH4D	2800 RPM	9 amps	20 amps
VG4D	2400 RPM	8 amps	17 amps

# FLYWHEEL ALTERNATOR 12 VOLT - 10 AMP and 25 AMP Systems

For Engines beginning with Serial Number 5188288

**SERVICE PARTS LIST:** The following items are in addition to, or replace similar parts found in the parts manual of each specific engine model. The parts illustration is for the VG4D engine, but can be applied to all models.



REF. NO.	DESCRIPTION	NO. REQ.	PART NUMBER PER ENGINE MODEL					
			AENL	AGND	S-10D, S-12D, S-14D	THD, TJD	VF4D, VH4D	VG4D
10	GEAR COVER ASSEMBLY BEARING RETAINER PLATE - flywheel end	1 1	BG-344-S1	BG-343-S1	BG-350A-S1	BD-103J-S1	BD-100K-4-S1	BD-101B-S1
* 11	FLYWHEEL with rotor and ring gear For 10 amp alternator circuit For 25 amp alternator circuit	1 1	N-104-5 N-104-9	N-103-5 N-103-9	N-105-2 N-105A-3	N-102-5 N-102-9	N-101-6 N-101-10	N-100-5 N-100-9
12	ROLL PIN - For 10 amp stator For 25 amp stator	2 2	PA-336 PA-362	PA-340 PA-340		PA-368 PA-340	PA-368 PA-340	PA-368 PA-340
13	LOCKWASHER, No. 10, for stator mt'g.	4	PE-14	PE-14	PE-14	PE-14	PE-14	PE-14
* 14	FLYWHEEL SHROUD	1	SE-154-A	SE-217-H	SE-289-A w/ SE-301B-1 PL.	SE-135-AT	SE-74-YA	SE-124-AM
15	SCREW - For 10 amp stator mt'g. For 25 amp stator mt'g.	4 4	XB-114 XB-110	XB-113 XB-106	XB-113 XB-106	XB-113 XB-106	XB-113 XB-106	XB-113 XB-106
16	STATOR ASSEMBLY - For 10 amp circuit For 25 amp circuit	1 1	YB-81 YB-82	YB-81 YB-82	YB-81 YB-82	YB-81 YB-82	YB-81 YB-82	YB-81 YB-82
17	INSULATOR - ammeter wire connector	1	YD-350	YD-350	YD-350	YD-350	YD-350	YD-350
18	WIRE ASSEMBLY - stator plug to ammeter For 10 amp stator For 25 amp stator	1 1	YL-381-6 YL-380-6	YL-381-6 YL-380-6	YL-381-18 YL-380-18	YL-381-14 YL-380-14	YL-381-18 YL-380-18	YL-381-22 YL-380-22
19	RECTIFIER MODULE - For 10 and 25 amp	1	YJ-68	YJ-68	YJ-68	YJ-68	YJ-68	YJ-68
20	REGULATOR MODULE - For 10 amp and 25 amp circuit	1	YJ-60	YJ-60	YJ-60	YJ-60	YJ-60	YJ-60

## PARTS REQUIRED - NOT ILLUSTRATED

* CRANKCASE	1	AA-91B-10	BA-54-20				
ENGINE BASE	1	BB-128A-5					
CLIP for stator wires	1	PG-630-1	PG-430				
GROMMET for stator wires	1			PH-198B-1			
GASKET for bearing retainer plate	1	QD-833					
NUT, #10-32, for mounting modules	4	PD-115	PD-115	PD-115	PD-115	PD-115	PD-115
LOCKWASHER, #10 I.E.T., for mounting modules	4	PE-78-A	PE-78-A	PE-78-A	PE-78-A	PE-78-A	PE-78-A
SCREW, #10-32, for mounting modules	4	XA-7	XA-7	XA-7	XA-8	XA-8	XA-8

\* NOTE: Because of the available variations in Flywheels, Flywheel Shrouds and Crankcases - give Engine Model, Specification and Serial Numbers when ordering.



# NEW! WISCONSIN Solid State Breakerless Ignition

WITH EXTERNALLY MOUNTED IGNITION MODULE

EYC 112 For Engine Model TRA-12D

EYC 113 For Engine Models S-12D, S-14D

## DESCRIPTION

Solid state *breakerless ignition* was designed to eliminate ignition maintenance and improve starting by electronically controlling the spark. A *magnet ring, ignition coil, stator* and *ignition module* are the basic parts of the solid state ignition system.

*No timing adjustment or breaker point setting* is necessary. The only mechanically moving part is the magnet ring, a component part of the flywheel.

## OPERATION

Alternating current is generated as the flywheel *magnet ring* passes over the coil poles on *stator* plate. The current is then directed through a *diode rectifier*, an electronic device that allows the current to flow in only one direction, thus changing the alternating current to direct current. The direct current then continues on to a *capacitor* where it is stored momentarily. As the flywheel continues to turn, the permanent *magnet* in the ring passes over a *trigger coil* which generates a small amount of current to the *solid state switch* (Silicon Controlled Rectifier). The SCR is triggered by this current and releases the stored up energy in the capacitor to the primary windings of the *ignition coil* where a high voltage is induced into the secondary windings and on into the *spark plug*.

The spark timing is permanently established by the position of the trigger coil in the stator plate, relative to the flywheel keyway. See illustration, Page 2.

## SERVICE REPLACEMENT

Beginning with engine serial No. 5,626,521 for model TRA-12D, and serial No. 5,635,132 for models S-12D, S-14D, the Single unit Stator Assembly is replaced by a Two Unit system consisting of a *stator* and separate *ignition module*. The Ignition Module contains the *rectifier, capacitor* and *SCR switch*, and is externally mounted to the shroud for service convenience.




Fig. 1 Wiring Diagram

The Two Unit system is completely *interchangeable* with the Single Unit system and is mounted and wired per Fig. 1, Fig. 2 and *Service Parts Illustration Page 2*.




Fig. 2 Ignition Module Mounting

## IGNITION TIMING - SPARK ADVANCE

The accuracy of the spark advance timing can be checked with a neon timing lamp and 12 volt battery. Timing, however, *cannot* be changed, since it is electronically controlled by the trigger coil on the stator plate. Connect lamp leads to positive terminal of battery, spark plug terminal and ground.

The spark is retarded 10 to 12° before top dead center for starting, and automatically advances as engine speed increases. The *running spark advance* (2500 R.P.M. and over) is 20°.

**Model TRA-12D:** The flywheel is marked with a groove to indicate the 20° running spark advance. With the engine operating at 2500 R.P.M. or over, the *timing mark* (groove) on rim of flywheel will appear *in line with timing pointer, left view, Fig. 3*.

**Models S-12D and S-14D:** The timing groove on the rim of flywheel, Fig. 3 (right), is marked for the 18° magneto and battery ignition advance, and timing can be checked to this mark for solid state ignition while the engine is running at 1000 R.P.M. When checking the 20° *running spark advance*, at 2500 R.P.M. or over, the *timing mark* (groove) will appear about 1/8 inch above the *timing pointer*.




Fig. 3 Ignition Timing

## IGNITION FAILURE

In the event of malfunction of the ignition system, check the following:


Broken, frayed, loose or disconnected ignition wires.

Faulty spark plug – wet, dirty, insulator broken or incorrect plug gap.


Check for spark – remove ignition cable from spark plug and wedge a piece of stiff bare wire into the terminal boot and leave one end of the bare wire extended. With the extended wire held about 1/8 inch from cylinder head shroud, turn engine over by means of the starter sheave or starting motor and observe the spark discharge which should occur during the cranking cycle. A weak spark or no spark at all will indicate a defective *stator* or *ignition module*.

First, plug a new *ignition module* into the circuit, if this does not correct the malfunction, then replace the *stator*.


It is unlikely that the ignition coil or ignition switch would become defective, however these parts can be checked with an ohmmeter. The ignition switch should indicate 0 ohms in the closed position and  $\infty$  in the open position. The ignition coil primary winding resistance is so low that it is inadvisable to try to measure it. The secondary winding, measured from the coil output to the coil case or ground, will indicate between 4000 and 6000 ohms. These static ohmmeter readings should be made with no external connections to the ignition switch or coil.

Stator must be mounted with the coils in a position relative to the vertical centerline of engine. 


### SERVICE PARTS LIST



### STATOR MOUNTING (facing flywheel end of engine) Model TRA-12D



### Models S-12D, S-14D



Ref. No.	PART NUMBER		Description	No. Req.	Ref. No.	PART NUMBER		Description	No. Req.
	Model TRA-12D	Models S-12D, S-14D				Model TRA-12D	Models S-12D, S-14D		
1	BG-351-S1	BG-350A-S1	BEARING PLATE ASSEMBLY, flywheel end (rep'l. std.)	1	12	PG-630-1	—	CLIP, stator harness support to tank bracket screw	1
2	N-106	N-105-4	FLYWHEEL with magnet ring (rep'l. std.)	1	STANDARD HARDWARE				
		N-105-3	FLYWHEEL with magnet ring and GH-48 ring gear	1					
3	PG-556	PG-556-2	STRAP for ignition coil	1	13	PE-4 (5/16")	PE-5 (3/8")	LOCKWASHER, spring lock, for mounting coil	1
4	PG-1144A	PG-1144A	CLIP for stator wire	1	14	PE-113	PE-113	LOCKWASHER, No. 10 internal tooth for mounting stator plate	4
5	YB-83	YB-83	STATOR ASSEMBLY YB-80 Previous to Serial No. 5626521-Replaced by YB83 S1 Stator and Module Kit.	1	15	PH-209B (5/16")	PH-513 (3/8")	PLAIN WASHER, for mounting coil	1
6	YJ-69	YJ-69	IGNITION MODULE	1	16	XB-113	XB-113	SCREW, 10-32 x 3/4" long, stator plate — wide flange section	1
7	YC-9F-S1	YC-9F-S1	IGNITION SWITCH ASSEMBLY	1	17	XB-115	XB-115	SCREW, 10-32 x 1/2" long (socket head), stator plate mounting	3
8	YD-20A	YD-20A	RUBBER NIPPLE for ignition coil cable	1	18	XD-162 (5/16"-18 x 2-1/2)	PC-588 (std. stud)	SCREW, hexagon head, for mounting coil	1
9	YF-37	YF-37	IGNITION COIL	1	19	XA-73	XA-73	SCREW, No. 7x3/8 lg. self-tap. for ignition module mounting	4
10	YL-339-6	YL-339-6	IGNITION CABLE, coil to spark plug	1					
11	YL-355-5	YL-355-5	WIRE ASSEMBLY, coil to ground (top shroud screw)	1					

# WALBRO CARBURETOR Model LMH

L-106  
series

For WISCONSIN Engine Models S-12D and S-14D

## L 106 (LMH-16) Fixed Jet

## L 106 A (LMH-18) Adjustable Jet

NOTE: The L 106 A Adjustable Jet carburetor replaces the L 106 Fixed Jet carburetor and is interchangeable for Production and Service requirements. An Adjustable Jet is included in the LQ 54 A Repair Kit so that Fixed Jet carburetors can be converted when carburetor overhaul becomes necessary.

### OPERATION, Fig. 1

Fuel from supply tank flows around float valve seat (1) through inlet valve (2) and into fuel bowl (3). As the level in fuel bowl increases, the float (4) rises, shutting off fuel supply by forcing inlet valve (2) into seat. As fuel is being used, the float lowers and allows additional fuel to enter bowl through the inlet valve.

Fuel from the bowl enters the main metering jet (5), then up to the main nozzle (7) where it is mixed with air from nozzle air bleed (8) and enters into venturi (9). At low idle speeds, fuel flows through the idle jet (10), up the idle channel (11), around idle adjustment (12) and into the emulsion channel (13), where it is mixed with air entering the idle air bleed. This air-fuel mixture then enters the throttle bore of carburetor through the outer idle hole. As the throttle is gradually opened, the inner idle hole starts to feed the throttle bore, and assists the main nozzle (7) in taking over the full throttle range.

When starting, the choke valve is closed and the throttle valve (14) is opened causing an abnormally high suction on both idle and main systems, thus providing a rich mixture for starting.

### CARBURETOR TROUBLES - CAUSES AND REMEDIES

Dirt is the major cause of field service carburetor problems: Service air filter daily - keep carburetor and linkage free of dirt.

#### FUEL LEAKS FROM CARBURETOR

Float level set too high: Remove bowl, invert carburetor and set float flush with bowl casting rim. See Fig. 2 and Float Setting Instructions, page 2.

Dirt under inlet valve: Remove inlet valve, clean seat by rinsing in clean fuel and blow off with compressed air.

Bowl vent plugged: Remove bowl and blow clean with compressed air.

Collapsed float, caused by blowing assembled carburetor with compressed air: Replace float.

Carburetor gummed from storage - float stuck: Remove fuel bowl and clean.

#### ENGINE SMOKES AND RUNS RICH

Dirty air filter: Clean per instructions.

Improper adjustment: Set Idle Needle 1 turn open from seat, Main Jet Adjustment 1-1/4 turns open. Refer to Adjustment Instruction, page 2.

Bowl retainer gasket leaks: Tighten securely, or replace.

Air bleed in carburetor plugged: Remove fuel bowl and idle needle. Clean thoroughly with compressed air.

#### ENGINE RUNS LEAN

Improper adjustment: Set Idle Needle 1 turn open from seat, Main Jet Adjustment 1-1/4 turns open. Refer to Adjustment Instructions, page 2.

Idle holes plugged. Dirt in fuel delivery channels: Remove fuel bowl and idle needle. Clean thoroughly with compressed air.

Low fuel level: Set float flush with bowl casting rim. See Fig. 2 and Float Setting Instructions page 2.

Fuel tank filter plugged: Remove and clean.

#### ENGINE STARTS HARD

Improper adjustment: Set Idle Needle 1 turn open from seat, Main Jet Adjustment 1-1/4 turns open. Refer to Adjustment Instructions page 2.




Fig. 1

No fuel in carburetor: Check carburetor drain valve. Clean tank, filter and carburetor.

Choke valve not closing: Check linkage for proper travel.

#### GOVERNOR SURGE

Governor sticking: Check linkage for binding.

Throttle shaft and valve binding: Remove and replace shaft if worn. Clean carburetor body and reassemble throttle shaft. Push assembly into carburetor body as far as possible.

#### DISASSEMBLY

Before disassembling: Clean outside of carburetor from all foreign material.

CAUTION: When cleaning a completely assembled carburetor, do not blow with compressed air, you may collapse the float.

DO NOT soak or boil carburetor or body in chemical solutions. Idle channel is permanently sealed - solution will seep in and cause corrosion.

Disassemble parts in the following sequence; Refer to exploded view, page 2.

- |                                 |                                   |
|---------------------------------|-----------------------------------|
| 1. Adjustable Jet screw ..(19)  | 10. Throttle stop screw .....(17) |
| 2. Retainer gasket .....(13)    | 11. Choke valve screws ....(18)   |
| 3. Fuel bowl .....( 4)          | 12. Choke valve .....( 8)         |
| 4. Retainer gasket .....(14)    | 13. Choke shaft .....( 7)         |
| 5. Fuel bowl gasket .....(12)   | 14. Throttle valve screws ..(18)  |
| 6. Float shaft .....(10)        | 15. Throttle valve .....( 6)      |
| 7. Float and spring ... (9, 24) | 16. Throttle shaft .....( 5)      |
| 8. Fuel valve-Spring .....(29)  | 17. Throttle shaft seal .....(28) |
| 9. Idle needle assembly ..(25)  | 18. Throttle return spring ..(23) |

CAUTION: Do not remove nozzle (Ref. 11) from carburetor, unless replacing it with a new service nozzle - idle holes will not line up. Tighten 30 to 40 inch pounds torque.

Viton seat for fuel valve can be replaced if necessary. Pull out by means of a small hook on the end of a wire paper clip.

Clean throttle shaft seal in gasoline and dry. Re-oil with No. 30 weight oil or equivalent.

## REASSEMBLY

Wash all other parts with carburetor cleaning solvent and blow off with compressed air.

Install choke shaft and valve. Mount valve with part number toward the outside with the valve in a closed position.

Mount throttle valve, with letter "W" on valve facing outward and opposite idle side of carburetor. Make certain valve plate does not bind when opening and closing throttle. Be sure that return spring tension holds throttle valve closed.

Viton fuel valve seat; press in place with groove end toward seat hole.

### FLOAT SETTING

Mount all other parts in reverse order of disassembly. Before mounting fuel bowl, check float setting per illustration, Fig. 2. Bend adjustment tab to raise or lower fuel level. Mount float support spring as shown.

### ADJUSTMENTS

Set Idle Needle 1 turn open from seat, and Main Jet Adjustment 1-1/4 turns open.




Fig. 3, EXPLODED VIEW




Fig. 2, FLOAT SETTING

Turn throttle stop screw in until throttle valve is slightly open.

Adjust idle mixture for smooth low running with throttle valve closed and engine running at about 1200 R.P.M.

Adjust throttle stop screw for the desired low idle speed.

Main Jet Adjustment: Turn adjustment until engine runs smooth at operating speed. If engine hesitates when speeding up from idle to high speed, open adjustment 1/8 to 1/4 turn at a time until hesitation is eliminated.

## SERVICE PARTS LIST

WISCONSIN L 106, L 106 A

SERVICE PARTS ARE THE SAME FOR BOTH CARBURETORS. Remove Fixed Main Jet (26), as used in L 106, and install Adjustable Main Jet (19) in place of fuel bowl retainer screw, thus converting to L 106 A.

Item No.	Part Number	Description	Qty.
2		THROTTLE BODY (not serviced) .....	1
3	83-19-19	LINK - throttle .....	1
4	83-20-513	FUEL BOWL with drain assembly .....	1
5	83-30-796	THROTTLE SHAFT assy-Incl. Items 23, 28	1
6	83-34-18	VALVE - throttle .....	1
7	83-40-693	CHOKE SHAFT - assembly .....	1
8	83-62-70	VALVE - choke .....	1
9	83-75-502	FLOAT - assembly .....	1
10	†	SHAFT - float .....	1
11	83-86-174	NOZZLE - main (service) .....	1
12	*	GASKET - fuel bowl .....	1
13	*	GASKET - bowl retainer - outer (red) ....	1
14	*	GASKET - bowl retainer - inner (black)..	1
15	*	GASKET - flange .....	1
16	*	GASKET - bowl drain .....	1
17	83-96-18	SCREW - throttle stop, 10-32 x 5/8 Fill. hd.	1
18	83-96-263	SCREW - throttle and choke valve No. 6 - 32 x 3/16 Pan head .....	4
19	†	ADJUSTABLE MAIN JET (L 106 A) .....	1
20	83-96-549	SCREW - swivel bracket retainer No. 4 - 40 NC x 5/16 Pan head ..	2
21	83-98-13	SPRING - choke stop .....	1
22	†	SPRING - idle needle, and stop (1 in Kit)	2
23	83-98-335	SPRING - throttle return .....	1
24	†	SPRING - float support .....	1
25	†	NEEDLE - idle .....	1
26	(obsolete)	JET - main fuel (L 106). Use Item 19 .....	1
27	83-154-503	KIT - bowl drain .....	1
28	83-156-18	SEAL - throttle shaft .....	1
29	†	FUEL VALVE and VITON SEAT .....	1
30	83-167-514	BRACKET - assembly with swivel .....	1
	† Q 46	GASKET SET (also included in Repair Kit) * Parts included in Q 46 Gasket Set	
	LQ 54 A	REPAIR KIT (Replaces LQ 54) † Parts included in LQ 54 A Repair Kit	